

# Maverix™

 **Outback**<sup>®</sup>  
GUIDANCE



**M<sup>7</sup>**



**M<sup>10</sup>**

**875-0490-10**

**Maverix Precision Ag Solution**

User Guide

Revision: **B1**

Date: May 16, 2022

# Table of Contents

Device Compliance, License and Patent .....	1
Technical Support .....	2
Terms and Definitions.....	3
<b>Chapter 1: Getting Started .....</b>	<b>4</b>
Overview.....	4
Product Overview .....	5
MaverIX Cable Diagram .....	6
Installing the MaverIX System .....	7
Mounting the Terminal .....	7
Mounting the Antenna .....	8
Connecting to a Power Source.....	9
Routing the Antenna Cable .....	9
Installing Optional Parts .....	10
Installing the Run/Hold Switch .....	10
Installing the Rover Radio .....	10
MaverIX Screen Overview.....	11
Overview .....	11
Home Screen.....	11
Status Ribbon .....	12
Map Touch Gestures .....	13
<b>Chapter 2: Start Up .....</b>	<b>14</b>
Overview.....	14
Powering Up the System .....	15
MaverIX Start-Up .....	16
Disclaimer .....	16
Start Up Menu .....	17
Using MaverIX.....	18
<b>Chapter 3: Job Mode.....</b>	<b>19</b>
Overview.....	19
Job Mode .....	20
Widgets.....	21
Slide-Out Menus .....	22
Workscreens .....	23
Main Menu .....	24
Job Menu .....	25
Guidance Mode Menu .....	26
Boundary Menu .....	27
Marker Menu.....	28
Jobs Settings Menu.....	29
Job .....	29
Alarms .....	37

Layers .....	38
Visualization .....	42
<b>Chapter 4: Widgets .....</b>	<b>45</b>
Overview .....	45
Working with Widgets .....	46
Workscreen .....	46
Widgets .....	46
Selecting/ Editing Workscreen .....	47
Default Widgets .....	48
Pre-Engage .....	49
Map View Perspectives .....	50
Info Widgets .....	51
Job Widgets .....	52
Job Menu .....	53
Boundary Menu .....	54
Counter Widgets .....	55
Guidance Widgets .....	56
Guidance Menu .....	57
AB Menu .....	58
A+ Direction Menu .....	58
AB Contour .....	59
Freeform Contour .....	59
Pivot .....	60
AB Closed .....	60
XTrack Widget .....	61
Application Widgets .....	62
Automatic Section Control (ASC) .....	63
Section Control .....	63
AC110 Widgets .....	64
<b>Chapter 5: Machines .....</b>	<b>65</b>
Overview .....	65
Machines Menu .....	66
Vehicles .....	67
Create Vehicle .....	68
Vehicle Information .....	72
Vehicle Dimensions .....	73
Boom Offset .....	75
Antenna Offset .....	76
Sections .....	79
Overlap/Skip .....	80
Application .....	80
Vehicle Calibration .....	81
Mounting Calibration .....	82

Valve Type .....	84
Wheel Angle Estimation Calibration.....	84
Wheel Lock Calibration.....	86
Estimate Open-Loop Gain Calibration .....	87
Mechanical Play Calibration .....	88
Guidance .....	92
Engage.....	92
Implements .....	94
Create Implement .....	95
Implement Information.....	99
Implement Dimensions .....	100
Measuring Implement Dimensions .....	102
Sections .....	103
Overlap/Skip.....	104
Implement Offsets.....	105
AC110.....	109
Implement Setup .....	109
Valve Setup .....	110
AC110 Calibration .....	112
Sensor Setup .....	114
Calibration Values .....	115
<b>Chapter 6: GPS .....</b>	<b>118</b>
Overview.....	118
GPS Menu .....	119
GPS Status.....	120
Settings .....	122
NMEA Input.....	122
NMEA Output.....	123
Correction .....	127
SBAS .....	127
Atlas .....	128
RTK Radio .....	129
RTK Radio Detection.....	130
RTK Radio Link.....	132
RTK Radio – RSSI Update .....	135
RTK NTRIP .....	137
RTK NTRIP .....	138
RTK NTRIP Settings .....	139
GPS Log .....	142
Simulator .....	145
Touch Screen Simulator .....	146
<b>Chapter 7: Diagnostic.....</b>	<b>148</b>
Overview.....	148

Diagnostic Menu .....	149
GNSS .....	150
GPS Menu.....	150
Receiver.....	152
RTK Status .....	153
Subscriptions .....	155
Update.....	155
Terminal .....	156
Information .....	156
Review.....	157
Records.....	158
ESi2.....	159
Information .....	159
AGS.....	159
Steering Test .....	160
Wheel Control Test .....	160
eDrive.....	161
Information .....	161
Events.....	162
Status Menu .....	162
Configuration Menu .....	162
Update.....	163
AC110.....	164
Information .....	164
Ports .....	165
Update.....	165
Logs .....	165
<b>Chapter 8: Files .....</b>	<b>166</b>
Overview.....	166
File & Data Management.....	167
File Browser .....	168
File Types .....	169
File Sorting .....	170
USB Transfer .....	171
Deleting Files .....	173
Job Summary .....	175
<b>Chapter 9: System.....</b>	<b>177</b>
Overview.....	177
Introduction .....	177
Contents.....	177
System Menu .....	178
General .....	179
Information .....	179

International .....	181
Interface .....	184
Screen .....	184
Sound .....	187
Touch .....	189
Wireless .....	192
Wi-Fi.....	193
Activations .....	195
Licenses.....	195
Subscriptions.....	195
Enter Code .....	196
Registration.....	197
Downloads Menu.....	197
System .....	198
Updates.....	198
Plugins .....	200
<b>End User License Agreement.....</b>	<b>201</b>
<b>Warranty Notice .....</b>	<b>206</b>

---

# Device Compliance, License and Patent

---

## Device Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This product complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at [HTTPS://HEMISPHEREGNSS.COM/ABOUT-US/QUALITY-COMMITMENT](https://hemispheregnss.com/about-us/quality-commitment).

The product has a Wi-Fi/BT module with the following certifications:

- **FCC ID:** 2AC7Z-ESPWROOM32D
  - **IC :** 21098-ESPWROOM32D
- 

## Copyright Notice

Copyright Hemisphere GNSS, Inc. (2022). All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Hemisphere GNSS.

---

## Trademarks

Hemisphere GNSS®, the Hemisphere GNSS logo, TRACER™, Crescent®, Eclipse™, e-Dif®, L-Dif™, PocketMax™, S320™, SBX-4™, Vector™, XF1™, XF2™, Cygnus™, Aquila™, and Lyra™ are proprietary trademarks of Hemisphere GNSS, Inc. Outback Guidance™, EDRIVE™. Other trademarks are the properties of their respective owners.

---

## Patents

Hemisphere GNSS products may be covered by one or more of the following patents:

US Patents			
6111549	6876920	7400956	8000381
6397147	7142956	7429952	8018376
6469663	7162348	7437230	8085196
6501346	7277792	7460942	8102325
6539303	7292185	7689354	8138970
6549091	7292186	7808428	8140223
6711501	7373231	7835832	8174437
6744404	7388539	7885745	8184050
6865465	7400294	7948769	8190337
8214111	8217833	8265826	8271194
8307535	8311696	8334804	RE41358

Australia Patents	
2002244539	2002325645
2004320401	

---

*Continued on next page*

## Device Compliance, License and Patent, Continued

---

### Notice to Customers

Contact your local dealer for technical assistance. To find the authorized dealer near you:

Outback Guidance  
A Division of Hemisphere GNSS  
2207 Iowa Street  
Hiawatha, KS 66434  
Phone: (800) 247-3808  
[WWW.OUTBACKGUIDANCE.COM](http://WWW.OUTBACKGUIDANCE.COM)

Dealer Locator:  
[HTTPS://WWW.OUTBACKGUIDANCE.COM/SUPPORT/DEALER-LOCATOR](https://WWW.OUTBACKGUIDANCE.COM/SUPPORT/DEALER-LOCATOR)

---

### Technical Support

If you need to contact Technical Support:

Outback Guidance  
A Division of Hemisphere GNSS  
2207 Iowa Street  
Hiawatha, KS 66434  
Phone: (800) 247-3808  
EMAIL: [SUPPORT@OUTBACKGUIDANCE.COM](mailto:SUPPORT@OUTBACKGUIDANCE.COM)

KNOWLEDGEBASE:  
[HTTPS://OUTBACKGUIDANCE.ZENDESK.COM](https://OUTBACKGUIDANCE.ZENDESK.COM)

---



## Terms and Definitions

---

The following table lists the terms and definitions used in this document.

<b>Term</b>	<b>Definition</b>
Activation	Activation refers to a feature added through a one-time purchase
Atlas	Atlas® is a subscription-based service provided by Hemisphere that enables the MaveriX to achieve sub-decimeter accuracy without a base station or datalink.
BeiDou	BeiDou is the global satellite system deployed and maintained by China.
DGPS/DGNSS	Differential GPS/GNSS refers to a receiver using Differential Corrections.
Elevation Mask	Elevation Mask is the minimum angle between a satellite and the horizon for the receiver to use that satellite in the solution.
Firmware	Firmware is the software loaded into the receiver that controls the functionality of the receiver and runs the GNSS engine.
GALILEO	Galileo is a global navigation satellite system implemented by the European Union and the European Space Agency.
GLONASS	Global Orbiting Navigation Satellite System (GLONASS) is a Global Navigation Satellite System deployed and maintained by Russia.
GPS	Global Position System (GPS) is a global navigation satellite system implemented by the United States.
RTCM	Radio Technical Commission for Maritime Services (RTCM) is a standard used to define RTK message formats so that receivers from any manufacturer can be used together.
RTK	Real-Time-Kinematic (RTK) is a real-time differential GPS method that provides better accuracy than differential corrections.
SBAS	Satellite Based Augmentation System (SBAS) is a system that provides differential corrections over satellite throughout a wide area or region.
Subscription	A subscription is a feature that is enabled for a limited time. Once the end-date of the subscription has been reached, the feature will turn off until the subscription is renewed.
WAAS	Wide Area Augmentation System (WAAS) is a satellite-based augmentation system (SBAS) that provides free differential corrections over satellite in parts of North America.

---

# Chapter 1: Getting Started

## Overview

---

**Introduction** This User Guide provides information to help you set up and use your MaveriX Precision Ag software application system.

You can download this manual from the Outback Guidance website at [WWW.OUTBACKGUIDANCE.COM](http://WWW.OUTBACKGUIDANCE.COM).

---

## Contents

Product Overview .....	5
MaveriX Cable Diagram .....	6
Installing the MaveriX System .....	7
Mounting the Terminal .....	7
Mounting the Antenna .....	8
Connecting to a Power Source .....	9
Routing the Antenna Cable .....	9
Installing Optional Parts .....	10
Installing the Run/Hold Switch .....	10
Installing the Rover Radio .....	10
MaveriX Screen Overview .....	11
Overview .....	11
Home Screen .....	11
Status Ribbon .....	12
Map Touch Gestures .....	13

---

# Product Overview

---

## Terminal Overview

Figure 1-1 shows the MaveriX system terminal front and rear views. Table 1-1 describes each numbered feature.




Figure 1-1: MaveriX Terminal front and back views

Table 1-1: Terminal features

Item	Description
1	Touch screen
2	USB Port
3	Power Button
4	Wi-Fi Antenna
5	Mounting Ball Area
6	COM1 Port
7	COM2 Port
8	LAN/USB Port
9	Power Port

# MaveriX Cable Diagram



- TERMINAL ONLY
- AUTOSTEER
- ES2 OR HYDRAULIC/STEER READY
- RATE & SECTION CONTROL
- ROVER RADIO
- SERIAL 2 & GSI OUTPUT
- SERIAL 1 & RUN/HOLD SWITCH OPTIONS



# Installing the MaveriX System


---

## Mounting the Terminal

Before you mount the terminal determine an appropriate mounting location. Place the terminal within easy reach and visibility of the driver; typically, this is in the front-right corner of the cab.

**WARNING:** Do not mount the terminal in a location where it impairs visibility of the controls or the field. Looking at the screen for a prolonged period while operating the vehicle can cause a crash.

1. Use the terminal mounting hardware to mount the terminal. Review the terminal mounting hardware (photo at right).
2. If necessary, loosen the knob on the arm mount and remove the ball mounts from the mounting assembly.



Using the below photo as a guide, complete the following steps:

3. Attach the round base to the back of the terminal using the screws provided.
4. Attach the bar mount base to your preferred location using the included U-bolt hardware.
5. Place one end of the arm mount over the ball of the bar mount base then tighten the knob enough so the arm mount stays attached.
6. Position the terminal so the round base fits in the open end of the arm mount then tighten the knob securely.
7. Adjust the terminal to your preferred viewing angle.



Figure 1-3: Terminal back view

*Continued on next page*

# Installing the MaveriX System, Continued

---

## Mounting the Antenna

The antenna should be installed on the vehicle's left/right centerline on the cab. If you cannot install the antenna at the exact centerline, refer to [Chapter 5, Antenna Offset](#) for instructions on entering offsets for these values.

**Note:** Do not place the antenna within two feet of a transmitting radio antenna (such as for a 2-way or business band radio).

1. Clean and dry the vehicle surface where you will attach the antenna mounting plate.
2. Remove the paper backing from the adhesive on the back of the mounting plate (see photo at right).
3. Position the mounting plate and press down hard for proper adhesion.
4. Attach the antenna to the antenna mounting base (see photo below).



5. Place the magnetic mounted antenna on the plate and on the vehicle's centerline and pivot point.

---

*Continued on next page*

## Installing the MaveriX System, Continued

---

### Connecting to a Power Source

Using the [Cable Diagram](#) as a guide, connect the power cable (P/N: 051-0430-10) to the battery or a 30-amp power source.

1. Connect red (+) to positive and black (-) to negative.
  2. Connect the other end of the power cable to the terminal cable P/N: 051-0431-10 (and if installed, ESI<sup>2</sup> cable P/N: 051-0441-10).
  3. Coil excess cable in a protected location then secure the installation with tie straps.
- 

### Routing the Antenna Cable

Adhere to the following when routing the antenna cable:

- Make sure the MaveriX terminal is powered-off before attaching the cables.
- Do not bend the cable to a radius of less than 6 inches.
- Do not route the cable within 12 inches of radio wires, power generator wires, a heat source, or moving parts.
- Coil excess cable in a protected location and secure the installation with tie straps.

To route the antenna cable:

1. Securely attach one end of the antenna cable to the antenna.
2. Route the cable through a cab opening where rubber protection exists that will protect the cable (see photo at right).



See the [Cable Diagram](#) for cable connections.

---

*Continued on next page*

# Installing Optional Parts

---

## Installing the Run/Hold Switch

Use the **Run/Hold** switch as a remote to pause or restart MaveriX's mapping/data logging function (similar to using the **Apply Widget** on the screen - refer to [Chapter 4](#) for more information on the **Apply Widget**).

Refer to the specific installation guide for each **Run/Hold** switch installation.

1. Connect the **Run/Hold** switch cable of the COM2 cable to the **Run/Hold** switch.
2. Install the **Run/Hold** switch in an easily accessible position.

---

## Installing the Rover Radio

Mount the rover radio on top of the vehicle cab to ensure line-of-sight to the RTK base station. The bottom of the rover radio includes a built-in magnet for easy placement on the included mounting plate.

1. Clean and dry the vehicle surface where you will attach the rover radio mounting plate.
2. Remove the paper backing from the adhesive strips on the back of the mounting plate (see photo at right).
3. Position the mounting plate and press down hard for proper adhesion.
4. Place the rover radio on the plate.
5. Attach the rover radio antenna to the rover radio, tightening until snug.





# MaveriX Screen Overview

---

## Overview

This section helps the user understand the primary areas of the MaveriX terminal and the basic screen gestures.

---

## Home Screen



The **MaveriX Precision Ag Home Screen** displays the following primary areas:

- **Job Mode** – is the main working mode and includes the map view for the Precision Ag operation.
- **Machines Menu** – allows the user to set up and manage different vehicles and implements.
- **GPS Menu** – is used to observe the status of the GNSS receiver and to adjust the corresponding configuration.
- **Diagnostic Menu** – is used to diagnose the MaveriX Precision Ag system and to connect all the system components.
- **Files Menu** – allows the user to manage and import/export the different file types (i.e., jobs, machines, prescriptions, etc.)
- **System Menu** – gives access to all the system settings.



*Continued on next page*

# MaveriX Screen Overview, Continued

## Status Ribbon

The **Status Ribbon** is found at the top of the screen:



The **Status Ribbon** provides key information that is always available for the user. This includes the following:

- GNSS Status
- Time
- Sound Status

There are other options that will be shown if they are enabled.

**Note:** Some options are under development and will be available in future MaveriX versions.



**Table 1-2: Status Bar Options**

Image	Description	When Displayed
	GNSS signal status and strength	Always displayed. For more information see <a href="#">Chapter 6</a>
	Tilt Compensated GNSS	After selected vehicle is calibrated. For more information see <a href="#">Chapter 5</a>
	Cloud Service (not used at this time)	Always displayed. For more information see <a href="#">Chapter 9</a>
	Wi-Fi connection	Wi-Fi option is enabled. For more information see <a href="#">Chapter 9</a>
	Router (not used at this time)	When Router is enabled. For more information see <a href="#">Chapter 9</a>
	Power system off	When enabled. For more information see <a href="#">Chapter 9</a>
	Current Time	Always displayed. For more information see <a href="#">Chapter 9</a>
	Save in Process	Displayed when job is being saved.
	System volume	Always displayed. For more information see <a href="#">Chapter 9</a>
	Screenshot	When enabled. For more information see <a href="#">Chapter 9</a>
	CPU usage information	When enabled. For more information see <a href="#">Chapter 9</a>

*Continued on next page*





## MaveriX Screen Overview, Continued

---

### Map Touch Gestures

To change zoom and focus on the **Job Mode** map, use the touch gestures described in the following table:

Table 1-3: Touch Gestures

	Zoom In
	Zoom Out
	Pan Focus
	Reset Zoom and Focus

# Chapter 2: Start Up

## Overview

---

**Introduction** This chapter explains how to power on/off and use the MaveriX Precision Ag System.

---

## Contents

Powering Up the System .....	15
MaveriX Start-Up.....	16
Disclaimer .....	16
Start Up Menu .....	17
Using MaveriX .....	18

---


## Powering Up the System

---

### Power On/Off

Depending on the components of your system, below outlines how to power on/off the system.

1. If you are using the terminal only, press and hold the power button on the top of the terminal (refer to [Terminal Overview](#)) for approximately 3 seconds.
2. If autosteer is installed, the 3-position switch, (P/N: 051-0434-10), turns the entire system on and off.
  - i. The top position enables autosteering
  - ii. The middle position will disable autosteering but leave everything else powered on and communicating
  - iii. The bottom position powers system off, after a countdown, displayed on screen.



- Autosteer enabled

- Power on/Roading mode

- Power off

**Note:** If using the 3-position switch to power off the system when the switch is in the **Off** position, the screen displays **Turning Off** after 10 seconds. The user can override a power off by repositioning the 3-position switch to the middle or top position before the screen displays the **Turning Off** message.

# MaveriX Start-Up


---

## Disclaimer

Each time the MaveriX terminal is powered on, the first screen to display is the **Disclaimer** screen. The user should read and understand all the safety information for the guidance and auto-steering systems before operation or service.

To read the full End User Agreement, press the green arrow to proceed to the next screen or see the [End User License Agreement](#) section at the end of this user guide.

The user is required to select the **I Accept** button to proceed to the **Start Up Menu** screen.



*Continued on next page*

# MaveriX Start-Up, Continued

---

## Start Up Menu

The **Start Up Menu** lists the current vehicle profile, the implement profile, and the last job. To proceed select one of the following options:

- New Job - start a new job
- Continue Job - continue last job
- Previous Jobs - open job list to select previous job
- Skip - skip this step and go to the Job Screen

**Note:** If the MaveriX system does not have **GNSS** correction, **Skip** is the only available option. The user can start a new **Job**, or open existing **Job** after **GNSS** is acquired.




*Continued on next page*

## Using MaveriX

The MaveriX System requires the following to utilize the mapping:

- GNSS Correction
  - **GNSS Correction** can be confirmed by the **GNSS Widget**. For more information, see [Chapter 4](#).



- A job must be open.
  - This can be confirmed using the **Job Menu Widget** or the **Job Menu**.

Job Menu Widget	Job Menu
	

- Validate the **Close Job** option is available. For more information, see [Chapter 4](#).



- Vehicle (and implement in most cases)
    - The MaveriX terminal uses the last vehicle and implement profiles applied, or MaveriX uses the default profiles if no others exist.
    - The user must create a vehicle before use. To create, calibrate, edit, or delete a vehicle or implement, refer to [Chapter 5: Machines](#) for more information.
-



# Chapter 3: Job Mode

## Overview

---

**Introduction** This chapter explains how to operate the MaveriX system when in **Job Mode**.

---

## Contents

Job Mode.....	20
Widgets .....	21
Slide-Out Menus.....	22
Workscreens.....	23
Main Menu .....	24
Job Menu.....	25
Guidance Mode Menu .....	26
Boundary Menu.....	27
Marker Menu .....	28
Jobs Settings Menu .....	29
Job.....	29
Alarms .....	37
Layers .....	38
Visualization.....	42

---


# Job Mode

---



The main **Job Mode** view includes the below key areas for status updates and navigation while working in this mode.

- Status Ribbon
- Slide-out menu-right
- Slide-out menu-left
- Widgets
- Map view with machine



# Widgets

---



A **Widget** provides access to a certain functionality or menu of the MaveriX Precision Ag system while the user is operating the system in **Job Mode**.

Widgets are a key component of the user interface, as they can be added/removed and arranged based on the user preference.

Each **Widget** has a unique appearance and can be used to configure the chosen **Workscreens** as desired by the user.



**Note:** See [Chapter 4 Widgets](#) to learn how to configure the **Workscreens** based on your preference.

## Slide-Out Menus

---



The **Job Mode** screen provides two slide-out menus that can be entered by swiping to the center of the screen from the outside bezel of the terminal:

- Slide-out menu right – **Main Menu**
- Slide-out menu left – **Workscreens**



## Workscreens

---



The left slide-out menu provides access to the **Workscreens**. This menu switches in real time between six pre-sets that can be adjusted by the user with the following configurations:

- Map view
- Displayed Widgets
- Location of Widgets



The left slide-out menu closes automatically but can also be closed manually by swiping the white arrow to the left or pressing the yellow back button (below).



Press the desired number of the Workscreens (1 to 6) to use for the current job.

**Note:** See [Chapter 4 Widgets](#) to learn how to configure the **Workscreens** based on your preference.

# Main Menu

---



The **Main Menu** is located on the right-side slide-out menu.

- **Job Menu**
- **Guidance Mode Menu**
- **Boundary Menu**
- **Markers Menu**
- **Job Settings**



The **Main Menu** closes automatically but can also be closed manually by swiping the white arrow to the right.

To navigate through the **Main Menu**, the individual buttons with symbols are used to enter the corresponding menu. The yellow arrow functions as a **back** button and allows the user to return to the previous menu.



# Job Menu

---



The **Job Menu** allows the user to setup and manage jobs while working in **Job Mode**.

	Start a new job
	Continue a previous job
	Open a previously saved job
	Create a new job from a template
	Close Job (only available if job is open)

**Note:** The **Job Menu** can also be reached using the **Job Widget**.



# Guidance Mode Menu

---



The **Guidance Mode Menu** allows the user to set up and manage guidance lines within the map.

	AB Menu
	A+ Direction Menu
	Freeform Contour
	AB Contour Menu
	Pivot Menu
	AB Closed Menu

**Note:** The **Guidance Mode Menu** can also be reached using the **Pattern Widget**.









# Boundary Menu

---



The **Boundary Menu** allows the user to set up and manage field boundaries.

	Select left boundary
	Select right boundary
	Close boundary
	Cancel boundary

**Note:** The **Boundary Menu** can also be reached using the **Boundary Widget**.







## Marker Menu

---



The **Marker Menu** can be utilized to mark specific locations (i.e., obstacles or landmarks) within a **Job Map**.

	Rock
	Tree 1
	Tree 2
	Lake
	Erase last created marker in map
	Erase all created markers in map

---

## Jobs Settings Menu

---




The **Jobs Settings Menu** allows the user to view and control settings associated with **Job Mode**.


---

## Job

---




The **Headland Menu** allows the user to adjust settings associated with **Headland Turn** and **Headland alarms**.




- **Headland turn**-displays the minimum headland width.
- **Number of passes**-adjust the number of passes inside the boundary for Automatic Section Control (ASC).
- **Proximity warning**-allows the user to select either Time or Distance and set the value for the alarm.
- **Activate alarms**-can be turned on or off by using the corresponding checkmarks.

---


*Continued on next page*



To adjust **Number of passes** the user can either use the + and – buttons or double-press on the number to open a keypad to type in value.



To make changes to the **Proximity warning**, the user can press to select either **Time** or **Distance** by pressing on drop-down arrows. To change the value, double-press on the **Value** box to open the number pad.



To activate/deactivate **Headland proximity** and **Headland entry alarms**, press on the corresponding checkmark:




-On




-Off

*Continued on next page*



The **Machine Menu** contains options pertaining to **Guidance**.



Guidance options:

- **Pre-engage** – enables user to activate autosteering before all engage requirements are met. After requirements are met, MaveriX automatically engages on a guideline. Pre-Engage works with all guidance modes. Although user enables Pre-Engage only once, you must manually press the **Engage** button each time you want to activate it.
- **Speed Sign Synchronizer** – *development purposes only, should be left on.*
- **Contour lock** – enables user to stop MaveriX from searching for the closest swath. In Contour Lock mode, guidance:
  - Remains locked on its current swath until you manually unlock it
  - Automatically unlocks if you drive offline by 2 m (or 10% of the swath width) and begins searching for the closest swath again

To activate or deactivate any **Guidance** options, press on the correlating checkmark:



-On




-Off

*Continued on next page*

- Options
- Job
- Headland
- Machine
- Prescription
- ASC
- Spraying
- Tank
- Alarms
- Spraying
- Layers
- Speed
- Spraying
- Coverage
- Prescription
- Visualization
- Soil
- Guidance
- Spraying

### Smoothing level



Smoothing determines the amount of smoothing of contours and applies to Contour paths and AB Contour paths. The smoothing applied to the current contour is based on the smoothing setting that was active during the preceding pass. Depending on preference and needs, smoothing can be adjusted to None (the default), Low, Medium, or High. For example, you may need to adjust the smoothing if a vehicle/implement combination does not allow turning within a tight radius or a very sharp curvature may not be desired during high-speed operation. Use the following table as a guide to set the smoothing.


**Table 3-1: Smoothing settings**

Setting	Minimum Radius	Performance
Off (default)	5 m	System tries to follow every contour, even if the contour has a very tight curvature but may disengage when following a very tight turn.
Low	10 m	System applies minimum smoothing.
Medium	15 m	System applies medium smoothing.
High	20 m	System generates optimized control paths for high-speed operation where the minimum curvature for each turn is large. It is not suitable for tight-turn operations as unwanted coverage gaps may occur.
<p><b>Note:</b> MaveriX cannot generate the correct path if the curve diameter is less than twice the minimum radius.</p>		


*Continued on next page*

# Job, Continued

---




The **Prescription Menu** is for future development. It is currently unsupported.



---

*Continued on next page*



The **ASC (Automatic Section Control) Menu** allows the user to adjust the percentage of the section that must be outside the apply area before shutting off the section. 100% is the entire section.

If AC110 is being used for section control, the percentage set will control the sections' shut off times. If no AC110 is being used, the setting will only be used for mapping purposes.




To change the **Percentage**, the user can use the + and – buttons, or double-press on the value to open a number pad.


---

*Continued on next page*







The **Spraying** menu is for development purposes only.




*Continued on next page*




The **Tank Menu** is for development purposes only.



# Alarms



The **Spraying Menu** allows the user to set the parameters for alarms associated with Application.



The **Activate after** is used to set the amount of time after a tolerance level is reached the alarm will activate.

The **Application tolerances** is used to set the percentage above or below target rate for an alarm.

The **Tank tolerance** is where the user can enter the minimum tank level for an alarm to notify the user.

To activate/deactivate **Application tolerances** and **Tank tolerance**, press on the corresponding checkmark:




-On




-Off

Once activated, the user can adjust percentage or amount by using the + (increase) and – (decrease) buttons or by double-pressing inside the box to open a number pad.

# Layers



The **Speed Menu** is where the user can adjust settings for the **As Applied** layer for speed.




**Note:** See the **As Applied Widget** for more information.

To turn on/off the As Applied **Speed Layer** option, use the **Visible** button.




*Continued on next page*

# Layers, Continued



The **Configuration** section allows the user to adjust the following information with the **speed layer**: the minimum (initial value) and maximum (final value) speed, limit the minimum (start) and maximum (ending) speed, and opacity of the layer.



The last section of this screen displays the correlating color and speed values. If **Manual** reference is **off**, the default values are used. If **Manual** reference is on, the user can adjust the values for each color, and change the color.

Manual references



	Color	Minimum	Maximum
1		20.0	+
2		17.5	20.0
3		15.0	17.5
4		12.5	15.0
5		10.0	12.5
6		7.5	10.0
7		5.0	7.5
8		2.5	5.0
9		0.0	2.5
10		<	0.0

Manual references


10

	Color	Minimum	Maximum
1		20.0	+
2		17.5	20.0
3		15.0	17.5
4		12.5	15.0
5		10.0	12.5
6		7.5	10.0
7		5.0	7.5
8		2.5	5.0
9		0.0	2.5
10		<	0.0


To adjust any number values, double-press the desired value, and a number pad displays. To adjust the color, double-press on the corresponding box to open a color picker screen. Adjust the color with the slider on the left and the shading on the right.



*Continued on next page*



The **Spraying Menu** is where the user can adjust settings for the **As Applied** layer for Applied rates.



**Note:** See the **As Applied Widget** for more information.


To turn on/off the As Applied **Spraying Layer** option, use the **Visible** button.




When the **Manual references** button is turn on, the user will be able to adjust the color and values associated with each level. *For more information on changing values, see the previous page on Configuration.*

Continued on next page



# Layers, Continued



The **Coverage Menu** allows the user to select the colors of the **As Applied** data and opacity.




To change either the **Covered** or **Overlapped** color, double-press on the correlating box to open a color picker screen. Adjust the color with the slider on the left and the shading on the right.




The **Prescription Menu** is for future development. It is currently unsupported and is purposefully left blank.

# Visualization

---



The **Soil Menu** allows the user to select the mapping background.




Press on the desired image to change.

**Note:** Satellite images is for future development and is currently unsupported.


---

*Continued on next page*





The **Guidance Menu** allows the user to adjust the settings for **guidance** and **lightbar sensitivity**.



### Guidance options

- **Lateral passes** – with Lateral passes enabled, the **Job** screen will display guidance lines to the left and right of the current guidance line.
- **Working width** – with **Working width** enabled, the **Job** screen will display red lines for the implement's working width for the current guidance line.

To activate or deactivate **Guidance** options, press on the correlating checkmark:



-On




-Off


**Lightbar Sensitivity** can be adjusted by the slider bar from low to high.

---

*Continued on next page*



The **Spraying Menu** is for development purposes only.



# Chapter 4: Widgets

## Overview

---

**Introduction** This chapter discusses working with **Workscreens** and **Widgets**.

---

## Contents

Working with Widgets.....	46
Workscreen .....	46
Widgets.....	46
Selecting/ Editing Workscreen .....	47
Default Widgets.....	48
Pre-Engage.....	49
Map View Perspectives .....	50
Info Widgets .....	51
Job Widgets .....	52
Job Menu.....	53
Boundary Menu.....	54
Counter Widgets .....	55
Guidance Widgets .....	56
Guidance Menu .....	57
AB Menu .....	58
A+ Direction Menu .....	58
AB Contour .....	59
Freeform Contour.....	59
Pivot.....	60
AB Closed.....	60
XTrack Widget .....	61
Application Widgets .....	62
Automatic Section Control (ASC).....	63
Section Control .....	63
AC110 Widgets .....	64

---

## Working with Widgets

---

**Workscreen** The **Workscreens** are accessible from the left slide-out menu. Each **Workscreen** can be edited including:

- Adding **Widgets**
- Removing **Widgets**
- Moving **Widgets**

---

**Widgets** A **Widget** provides access to a certain functionality or menu of the MaveriX Precision Ag system while the user is operating the system in **Job Mode**.

**Widgets** are a key component of the user interface and can be added/removed and arranged based on the user preference.

Each **Widget** has a unique appearance and can be used to configure the chosen **Workscreen** as desired by the user.

The MaveriX application software offers **Widgets** for the following categories:

- Default
- Info
- Job
- Counter
- Guidance
- Application
- AC110

---

*Continued on next page*

# Working with Widgets, Continued

---

## Selecting/ Editing Workscreen

From the **Job Mode** screen, open the left slide-out menu by swiping in from the left edge of the screen. Here, you can select from the six customizable Workscreens. The user can also edit which **Widgets** are displayed and their location on the screen.



To edit a **Workscreen**, long-press the number you wish to customize.



To **Add a Widget** from the list on the left, long-press and drag the **Widget** to the desired location.














To **Remove a Widget**, drag it to the trash bin in the center of the screen.

To **Move a Widget**, drag it to the desired location on the screen.

When finished, select the **save** button in the lower-left of the screen.

---




# Default Widgets

Name	Menu View	On Screen View	Alternate Views		Function
Steering	N/A (Not removable)			Steering not available	-Enable automated steering -Disable automated steering -Review status of the steering system
				Engage criteria not met	
				Pre-engage available	
				Engage criteria met Ready to engage	
				Engaged	
Home	N/A (Not removable)		N/A	----	-Returns to the <b>Home</b> screen
Perspective	N/A (Not removable)			Field view 2D	-Toggles between the different supported perspectives (map views) of the <b>Job Mode</b>
				Top down 2D	
				3D	
				In cab 3D	
				Machine 3D	
<p><b>Note: Default Widgets</b> can be moved on the screen, but they cannot be removed from any <b>Workscreen</b>, as they are considered essential to the operation of the system.</p>					

*Continued on next page*






# Default Widgets, Continued


## Pre-Engage

	<p>When <b>Pre-Engage</b> is enabled a <b>P</b> appears on the upper-right of the <b>Engage</b> button.</p>
<p>Press the <b>Engage</b> button to activate <b>Pre-Engage</b> and MaveriX will automatically engage on the guideline when all autosteering criteria is met.</p> <p><b>Note:</b> You have 20 seconds to meet all the criteria—during this time, the <b>Engage</b> button flashes between the following states. If 20 seconds passes, reactivate <b>Pre-Engage</b> if outside of engage limits.</p>	
	
	<p>Once engaged on the guideline, the <b>Engage</b> button remains green. Repeat above steps as needed (i.e., for each swath).</p>
<p><b>Note:</b> For more information on <b>Pre-Engage</b> see <a href="#">Chapter 3: Job Mode &gt; Jobs Settings menu &gt; Job &gt; Machine.</a></p>	

# Default Widgets, Continued









## Map View Perspectives

View 1 	Field view 2D
View 2 	Top down 2D
View 3 	3D
View 4 	In cab 3D
View 5 	Machine 3D





# Info Widgets

Name	Menu View	On Screen View	Alternant Views	Function
GNSS			(If the <b>Widget</b> is tapped on the screen, it provides an extended view, shown below)	<ul style="list-style-type: none"> <li>- GNSS status</li> <li>- Number of satellites</li> <li>- GNSS quality</li> <li>- Correction age</li> <li>- HDOP</li> </ul>
				
Map Scale			-----	Displays map scale according to the zoom level in reference to the checkerboard background
Speed			(If the <b>Widget</b> is tapped on the screen, it provides an extended view, shown below)	<ul style="list-style-type: none"> <li>- Displays vehicle speed</li> <li>- Overrides direction detection</li> </ul>
				


# Job Widgets







Name	Menu View	On Screen View	Alternant Views	Function
Job Menu			(See <a href="#">Working view</a> )	Provides access to the <b>Job Menu</b> (same as accessed using the <b>Main Menu</b> ).
Boundary Menu			(See <a href="#">Working view</a> )	Provides access to the <b>Boundary Menu</b> (same as accessed using the <b>Main Menu</b> ).
Job Info				Job is open
				Job not open
			(Tap the <b>Widget</b> on the screen for an extended view, shown below.)	
As Applied				<ul style="list-style-type: none"> <li>- Provides additional information for coverage map layers</li> <li>- Toggles coverage layers</li> <li>- Provides legend for color-coding of the map</li> <li>- Shading and values are controlled in the <b>Job Settings Menu</b></li> </ul>
			<p><b>Total</b> – total acres inside the boundary.  <b>Covered</b> – total worked acres.  <b>Overlapped</b> – total overlapped acres.  <b>Uncovered</b> – total unworked acres.</p> <p><b>Note:</b> Will also display percentages of Total for the other categories, when boundary is used.</p>	

Continued on next page

## Job Widgets, Continued

### Job Menu









Icon	Function	When selected
	Start a new job	Maverix will auto name a new job, the user can re-name this. <b>Name</b> – Required <b>Field, Client, and Notes</b> – Optional
 OR 	Continue last job	- <b>Only available if job is closed</b> - Will open the last job
	Close Job	- <b>Only available if job is open</b> - Will close the job
	Open a previously saved job	- Opens the <b>Fields Menu</b> - User can view all the jobs on the Maverix system
	Create a new job from a job template	- If a job is open, will allow user to use current job for template. - If job is not open, or if user declines to use open job: - Opens <b>Fields Menu</b> - User can select job for use in template - Then select the attributes to use: - Layers - Boundaries - Patterns - Obstacles

*Continued on next page*












**Job Widgets, Continued**

**Boundary Menu**



Icon	Function	When selected	
	Select Left Boundary	When selected	
	Select Right Boundary	When selected	
	Close Boundary	When selected, MaveriX will close the boundary from the current position to the start of the boundary position, after confirmation.	
	Cancel Boundary	When selected, will cancel boundary, after confirmation.	










# Counter Widgets

Name	Menu View	On Screen View	Alternant Views	Function
Time Counter			(Tap the <b>Widget</b> on the screen for an extended view, shown below.)	- Count time - Reset count
				
Distance Counter			(Tap the <b>Widget</b> on the screen for an extended view, shown below.)	- Counts distance - Resets count
				
Area Counter			(Tap the <b>Widget</b> on the screen for an extended view, shown below.)	- Counts time - Resets count
				
Area/Time Counter			---	Counts coverage rate













**Note:** With the **Time**, **Distance**, and **Area** counter **Widgets**, the user can reset the measurement by pressing the **Reset** button.



# Guidance Widgets

Name	Menu View	On Screen View	Alternant Views	Function
Guidance Menu			---	Provides access to the <b>Guidance Menu</b> (same as accessed using the <b>Main Menu</b> ).
Previous Pass			(Tap the <b>Widget</b> on the screen for an extended view, shown below.)	<ul style="list-style-type: none"> <li>- Manages previous guidance path</li> <li>- Toggles between previous guidance lines</li> <li>- Erases previous guidance line</li> <li>- Chooses previous guidance line</li> </ul>
				
XTrack			See XTrack for more information.	<ul style="list-style-type: none"> <li>- Displays current <b>XTrack</b></li> <li>- Shift/Snap</li> <li>- Saves offset</li> <li>- Adjusts steering sensitivity</li> </ul>
Steering Guide				<ul style="list-style-type: none"> <li>- Provides manual guidance directions</li> <li>- Current position offset</li> <li>- Required steering angle</li> </ul>

# Guidance Menu


Name	Menu View	On Screen View	Working Screen Views	Function
AB Menu			See AB Menu	Provides access to the <b>AB Menu</b> (same as accessed using the <b>Main Menu</b> ).
A+ Direction Menu			See A+ Direction	Provides access to the <b>A+ Direction Menu</b> (same as accessed using the <b>Main Menu</b> ).
AB Contour Menu			See AB Contour	Provides access to the <b>AB Contour Menu</b> (same as accessed using the <b>Main Menu</b> ).
Freeform Contour			See Freeform Contour Guidance	- Enables <b>Freeform Contour Guidance</b> - Provides guidance path based off the applied area
Pivot Menu			See Pivot Menu	Provides access to the <b>Pivot Menu</b> (same as accessed using the <b>Main Menu</b> ).
AB Closed Menu			See AB Closed Menu	Provides access to the <b>AB Closed Menu</b> (same as accessed using the <b>Main Menu</b> ).

Continued on next page

# Guidance Menu, Continued

## AB Menu


Set up straight **AB** guidance path:



Icon	Function	Use
	Set A Point	Set the first point for an <b>AB</b> line.
	Set B Point	Set the second point for an <b>AB</b> line, after traveling a minimum of 65 feet from point A.
	Cancel	Cancel guidance setup after confirmation.


## A+ Direction Menu

Set up an **A+ Direction** guidance path:



Icon	Function	Use
	Set A Point	Set the first point for an A+ line
	N/A	<i>(Not used)</i>
	N/A	<i>(Not used)</i>

After the user sets the A point, a number pad displays. Enter the desired degrees from point A.



**Note:** Touch anywhere on the screen (except the number pad) to cancel setting the point A.

*Continued on next page*




# Guidance Menu, Continued

**AB Contour** Set up an **AB Contour** guidance path:



Icon	Function	Use
	Set A Point	Set the first point for an AB line.
	Set B Point	Set the second point for an AB line, after traveling a minimum of 150 feet from point A.
	Detour	When driving along an AB contour you can create a detour path around the obstacle. You then decide whether to end your path after steering around the obstacle or merge into the original AB contour after driving around the obstacle—in both instances you have created a new AB contour that combines the original AB contour and the detour.
	Cancel	Cancel guidance setup, after confirmation.

## Freeform Contour



**Freeform Contour** provides a guidance path based off the applied area. To activate **Freeform Counter**, select either the **Menu** or the **Widget** and the MaveriX will display **FreeForm Contour active**. As the machine approaches the range of the applied area, a guidance line is displayed.

*Continued on next page*

## Guidance Menu, Continued

---

### Pivot

Set up a **Pivot** guidance path:




Icon	Function	Use
	Set Center Point	Sets the center point of the pivot
	Set A Point	Set the first point for a pivot
	Set B Point	Set the second point for a pivot
	Cancel	Cancel guidance setup, after confirmation.

---

### AB Closed

Set up an **AB Closed** guidance path:













Icon	Function	Use
	Set A Point	Set the first point for an AB line.
	Set B Point	Set the second point for an AB line.
	Cancel	Cancel guidance setup, after confirmation.

---

# XTrack Widget

	Shift guidance lines left.
	Snap guidance line to vehicle's location, parallel to original guidance line.
	Shift guidance lines right.
	Save guidance offset changes.
	Amount to shift guidance lines.
	<p>Steering sensitivity.</p> <ul style="list-style-type: none"> <li>- Increasing percentage makes steering more aggressive.</li> <li>- Decreasing percentage make steering less aggressive.</li> </ul>

# Application Widgets

Name	Menu View	On Screen View	Alternant Views		Function
Apply				Apply On	<ul style="list-style-type: none"> <li>- Apply On</li> <li>- Apply Off</li> </ul>
				Apply Off	
Automatic Section Control (ASC)				ASC On	<ul style="list-style-type: none"> <li>- Enables ASC</li> <li>- Disables ASC</li> <li>- Configures <b>ASC boundary behavior</b></li> </ul>
				ASC Off	
Section Control			(See <a href="#">alternante views</a> )		<ul style="list-style-type: none"> <li>- Sections off</li> <li>- Sections force on (toggle sections status by pressing the section in <b>Widget</b>).</li> <li>- Sections in Auto mode</li> </ul>

*Continued on next page*


## Application Widgets, Continued

---


### Automatic Section Control (ASC)

If the **ASC Widget** is pressed, the user can configure the **ASC boundary** behavior.

- ASC inside the boundary
- ASC right at boundary
- ASC outside the boundary



If **ASC** is turned to **Off** this configuration is greyed out.




### Section Control

The **Section Control Widget** provides a visual reference and is used to change the section control configuration and status.

Section – On  
ASC – On




Section – Off  
ASC – On














Section – On  
ASC – Off



Section – Off  
ASC – Off



# AC110 Widgets

Name	Menu View	On Screen View	Alternat Views	Function
Pressure			---	<b>Future development</b>
Rate Options			(Tap the <b>Widget</b> on the screen for an extended view, shown below.) 	Displays and sets target rates for the AC110 application control. Toggles between <b>Manual</b> , <b>Rate 1</b> , <b>Rate 2</b> , and <b>Prescription Rate</b> .
Volume Counter			(Tap the <b>Widget</b> on the screen for an extended view, shown below.) 	- Counter to measure applied total volume - Reset (after confirmation)
Tank Level			(Tap the <b>Widget</b> on the screen for an extended view, shown below.) 	- Sets tank level - Monitors tank level

# Chapter 5: Machines

## Overview

**Introduction** This chapter describes working with machines, including both the vehicle and the implement.

<b>Contents</b>	Machines Menu .....	66
	Vehicles .....	67
	Create Vehicle .....	68
	Vehicle Information .....	72
	Vehicle Dimensions .....	73
	Boom Offset .....	75
	Antenna Offset .....	76
	Determining Antenna Offset – Track Method .....	77
	Determining Antenna Offset – Marker Method .....	78
	Sections .....	79
	Overlap/Skip .....	80
	Application .....	80
	Vehicle Calibration .....	81
	Mounting Calibration .....	82
	Valve Type .....	84
	Wheel Angle Estimation Calibration .....	84
	Wheel Lock Calibration .....	86
	Estimate Open-Loop Gain Calibration .....	87
	Mechanical Play Calibration .....	88
	Guidance .....	92
	Engage .....	92
	Implements .....	94
	Create Implement .....	95
	Implement Information .....	99
	Implement Dimensions .....	100
	Measuring Implement Dimensions .....	102
	Sections .....	103
	Overlap/Skip .....	104
	Implement Offsets .....	105
	Implement Offset – Preferred Method .....	106
	Implement Offset – Alternative Method .....	108
	AC110 .....	109
	Implement Setup .....	109
	Valve Setup .....	110
	AC110 Calibration .....	112
	Sensor Setup .....	114
	Calibration Values .....	115

# Machines Menu

---




The **Machines Menu** is used to setup and configure vehicles and implements for the MaveriX Precision Ag system.

The **Machines Menu** can be reached by following the Home > Machines menu.



This **Machines Menu** allows the user to **create new**, **edit**, or **select an existing vehicle** and **implement profiles**.

The MaveriX has a default vehicle and implement installed (see below). These cannot be deleted, and some fields are not editable. Users should create their own vehicle(s) and implement(s) before using the system.





# Vehicles

---




On the **Machines Menu**:

- Select an existing vehicle for use
- Select an existing vehicle to edit or delete
- Create a new vehicle

Swiping left or right will change the highlighted vehicle. To edit or create a new vehicle, highlight the desired selection, and press on it.

The highlighted vehicle will be used in the **Job Menu**.



## Create Vehicle


---



Click **Create new** to initiate a new vehicle setup:



The **New Vehicle Menu** displays.



*Continued on next page*

## Create Vehicle, Continued


---

### Vehicle Type and Color




Use the **Vehicle type** drop-down menu to choose the desired vehicle type to match your machine:

- Standard Tractor
- Articulated Tractor
- Rear Boom Sprayer
- Front Boom Sprayer



**Note:** Depending on the chosen vehicle type, the displayed 3D vehicle model will change accordingly. This also impacts the displayed 3D vehicle model displayed on the map during **Job Mode**.

Use the color configuration bar on the left side of the **New Vehicle Menu** to select the desired color of the vehicle.



The vehicle will change the color accordingly.

**Note:** The vehicle color configuration is optional but is not required to complete the vehicle setup.

---


*Continued on next page*

## Create Vehicle, Continued

---

### Vehicle Name

Identify the **Vehicle Name** area on the screen as shown below.




Press on the **Vehicle Name** area to open the keyboard.

**Note:** The **Vehicle Name** can only contain the following:

- Letters (a-z, A-Z)
- Numbers (0-9)
- Hyphens ( - )
- Underscores ( \_ )
- Spaces

Maximum length of 20-character spaces.

Type the desired **Vehicle Name** and press **Done**.



The **Vehicle Name** is now configured.

---

*Continued on next page*


# Create Vehicle, Continued

---

## Vehicle Model Year



Repeat the same process as **Vehicle Name** to configure the **Vehicle Model** and the **Vehicle Year**.



**Vehicle Model** can use any combination of letters, numbers, and symbols up to 8-character spaces.

**Vehicle Year** requires 4 digits for the year and must be dated between 1900-2099.


**Note:** The **Model** and **Year** configurations for the vehicle are optional, but the **Vehicle Name** is required to complete the configuration.

## Completing Vehicle Profile



Once the user has entered the information for the **vehicle profile**:

- Click the **Checkbox** button to complete a new vehicle setup.
- If the vehicle setup is no longer required, it can be canceled with the red X button.




This step completes the **Vehicle Information** setup.

---


*Continued on next page*

# Vehicle Information

---



Once the **Vehicle Information** setup has been completed, the screen will look as shown below:



The 3 button options on the right side of the screen are used to:



- Copy current vehicle profile.



- Edit current vehicle's information, including:

- Name
- Model
- Year
- Color



- Delete current vehicle.





---

# Vehicle Dimensions



The **Vehicle Dimensions Menu** is used to configure the following measurements that are specific to each vehicle and MaveriX Precision Ag system installation:

- Antenna Height
- Wheelbase
- Antenna –
  - Rear Axle (standard tractor, rear and front boom sprayer)
  - Front Axle (articulated tractor)
- Rear Axle – Tow Hitch (standard and articulated tractor)
- Antenna – Boom (rear and front boom sprayer)

Standard Tractor	Articulated Tractor
	
Rear Boom Sprayer	Front Boom Sprayer
	

*Continued on next page*

# Vehicle Dimensions, Continued

## Entering Dimensions



Double-click the desired dimension to change the setting for the individual vehicle:

- Will not accept a negative value
- Box around value will be green if entered value is acceptable, red if there is an issue.



Push **Enter** to confirm the setting.

**Note:** The system assigns a default dimension to each **vehicle type**. It is important for automated steering and application control to enter the specific machine measurements for each vehicle.

*Continued on next page*



# Vehicle Dimensions, Continued

---

## Measuring Vehicle Dimensions



Measure your vehicle's dimensions before adding the vehicle in the MaveriX Precision Ag system. When adding a vehicle, the system displays the vehicle dimensions for the vehicle type you select (standard tractor, sprayer, etc.).

**Antenna height** is the vertical distance of the antenna's measurement from the ground up. Typically, you place the antenna on the cab roof.

**Antenna – Rear axle and Antenna – Front axle** are the perpendicular distance of the antenna's center to the vehicle's pivot point. The vehicle's pivot point depends on the vehicle type, such as a standard tractor or articulated tractor.

**Note:** Measure the **Antenna – Rear axle and Antenna – Front axle** as accurately as possible, as this measurement has some impact on the accuracy of vehicle guidance and is also the reference point from which the implement offset is calculated. Unlike the antenna left/right offset, there is no suitable field method to verify or improve the measurement.


---

## Boom Offset



The **Boom Offset** is the lateral (perpendicular) distance between the center of the centerline of the boom and the centerline of the vehicle.

*(Only used for rear and front boom sprayer)*



# Antenna Offset

---




**Antenna Offset** is the lateral (perpendicular) distance between the center of the GNSS antenna and the centerline of the vehicle.

To achieve optimum steering accuracy, you must determine the **Antenna Offset** in the field. However, you need to complete the calibration procedure before you can conduct the field tests, and to complete vehicle calibration, you need to enter the antenna offset values on the **Vehicle Dimensions** screen. Because you do not have an accurate **Antenna Offset** when working through calibration, you have two options:

1. Leave the **Antenna Offset** as 0.00 and enter the measured offset later
2. Enter an estimated 'provisional' offset value (suggested if you have a noticeable **Antenna Offset** that you can measure or estimate).

When you have completed the vehicle calibration and determined the actual **Antenna Offset**, you can revisit the vehicle dimensions and add the actual value. See [Determining Antenna Offset – Track Method](#) and [Determining Antenna Offset – Marker Method](#), to find your machine's antenna offset measurement.




*Continued on next page*

# Determining Antenna Offset – Track Method

To determine the antenna offset using the track method:

1. Set an A=B path (see [AB Menu](#)).
2. Maintaining a speed of 5 kph (3 mph) engage steering and let the system steer you along the guideline for at least 100 m. See Pass 1 in the figure to the right.
3. Perform a keyhole turn, re-engage the steering, and let the system steer you down the same guideline. See Pass 2 in the figure to the right.
4. In three separate places along the A=B line, measure the distance between the corresponding track marks (inside edges, outside edges or centers, whichever are easiest to see and measure, see figure above). If there is variation, calculate the average difference. In the figure above the track difference is 6 cm, measured at the outside edges of the track marks at one point on the A=B line.




**Note:** Take your measurements where the vehicle was travelling with a crosstrack of between 0-1, that is, not just after re-acquiring the A=B line after your turn (this is sometimes referred to as ‘allowing settling time’). Halve the measurement (3 cm). This is the amount of the physical antenna offset—the offset you need to compensate for and need to enter as the antenna offset (in meters, 0.03 m) at step 7.

5. Determine the direction of the offset—this is the left or right direction of the antenna’s centerline relative to the vehicle centerline when viewed in the direction of travel.
6. Press Home > Machines > (vehicle) > Dimensions.

7. Enter the antenna offset:

- 1) Press the Antenna Offset field (white box).
- 2) Enter an offset value using the keypad, (a negative value is used for a left offset), then press the enter button to confirm the value and close the screen.




8. Test the completed calibration by letting the system control up and down a new AB path. The tracks should match. If they do not match, repeat the procedure for determining the antenna offset.

# Determining Antenna Offset – Marker Method

To determine the antenna offset using the marker method:


1. Set an A=B path (see [AB Menu](#)).
2. Maintaining a speed of 5 kph (3 mph) engage steering and let the system steer you along the guideline for at least 100 m. When the crosstrack has stabilized (0-1), place markers along the AB line—at least three—on the centerline of the vehicle (the hitch pinpoint). See Pass 1 in the figure to the right.



3. Perform a keyhole turn, re-engage the steering, and let the system steer you down the same guideline. When the crosstrack is stabilized (0-1), place more markers close to those placed on the first pass.

**Note: Place your markers while the vehicle is travelling with a crosstrack of between 0-1, that is, not just after re-acquiring the AB line after your turn (this is sometimes referred to as 'allowing settling time').**

4. Measure the distance between corresponding markers. In the figure above the centerline difference is 6 cm. Halve the measurement (3 cm). This is the amount of the physical offset of the antenna—the offset you need to compensate for and need to enter as the antenna offset (in meters, 0.03 m).
5. Determine the direction of the offset—this is the left or right direction of the antenna's centerline relative to the vehicle centerline when viewed in the direction of travel.
6. Complete steps 6 through 8 in [Determining Antenna Offset - Track Method](#).



# Sections



*(Only used for rear and front boom sprayer)*

In the **Sections** portion of the **Dimensions Menu**, the user can adjust the number of sections and the measurement of the sections. The total boom width is the sum of all the sections measurements.



When the sections' quantity is increased to 3 or more odd number of sections, the left measurement is for the center section, and the right measurement is for both the outside right and left sections. All are added together to achieve the total boom width.



When the sections' quantity is increased to 4 or more even number of sections, the displayed sections are mirrored for the left and right sections. All the sections are added together to achieve the total boom width.

# Overlap/Skip


---



*(Only used for rear and front boom sprayer)*

Enter a value to drive a pattern where rows intentionally **Skip** or **Overlap**.

When you enter a **Skip** or **Overlap**, the map shows this as an area between swaths in the green coverage lines where a **Skip** is the non-sprayed area between swaths and an **Overlap** is the dark green overlap between swaths.




Use the drop-down box to change between **Overlap** and **Skip**. To enter a value for **Distance**:

- Double-press on the value box to open a number pad for the user to type in the desired value.
- Use the – or + buttons to decrease or increase the value by .1 in for each press.

---

# Application

---



Only used with rear and front boom sprayer, with AC110.

For more information on setting up the Application section of the vehicle, please see [AC110](#) section of this chapter.

# Vehicle Calibration

---



If the system is used with an **eDriveM1** steering controller, the following vehicle calibration steps must be completed.

## Vehicle Calibration:

- Mounting Calibration
- Valve Type
- Wheel Angel Estimate
- Wheel Lock
- Estimate Open-Loop Gain
- Mechanical Play (***not required to complete calibration***)


## Before calibrating a vehicle:

- GNSS antenna is located in its final position and initialized.
  - Use the highest accuracy GNSS source the vehicle will use in operations (for example, if planning to use RTK in the field you must use RTK during calibration).
  - The 3-position switch, (P/N 051-0434-10) is in the top **Autosteer Enabled** position.
  - All calibration steps should be completed with the vehicle operating at least 1500 rpms.
-

# Mounting Calibration



The **Mounting** calibration will ensure that the mounting position is defined, and any mounting bias is compensated for.



1. Enter the direction of the top surface (logo label surface) of the eDriveM1 controller.
2. Enter the direction the connector is facing.

Acceptable ECU mounting orientations				
eDriveM1	✓	✓	✓	✗

Use the drop-down menus to make the required configuration to align with the specific installation for your machine.

**Note:** Improper configuration and calibration of the eDriveM1 mounting position will lead to erratic steering behavior and XTrack offset during automated steering.

*Continued on next page*




# Mounting Calibration, Continued




Initiate the calibration process by pressing the **Calibrate** button.  
Follow the onscreen messaging during the different calibration steps.

-  -PROCEED
-  -BACK
-  -RETRY
-  -CANCEL



After the first two steps, it is required to turn the vehicle around and park in the same position before the second part of the calibration can be initiated.



Utilize the green and yellow arrows to navigate between the different calibration steps. You can cancel the calibration with the red X if needed.




Ensure the calibration has been successful and confirm by pressing the green checkbox.

## Valve Type

---



The **Valve Type** configuration is required to configure the steering interface for the eDriveM1 controller.



Currently, only ESi2 is supported with the eDriveM1. Drop-down arrows are present for future expansion of valve types.

---


## Wheel Angle Estimation Calibration

---



The **Wheel angle estimate** is required to calibrate the eDrive ESi2 electric wheel in conjunction with the eDriveM1 steering controller.

The calibration populates the **Clockwise** and **Counterclockwise** wheel angle estimates.



**Note:** Depending on your vehicle, it is common that the **Clockwise** and **Counterclockwise** wheel angle estimate numbers are not identical.

---

*Continued on next page*


# Wheel Angle Estimation Calibration, Continued



Initiate the calibration process by pressing the **Calibrate** button.

Follow the onscreen messaging during the different calibration steps.

The wheel angle estimation calibration requires a smooth and clear surface with a diameter of ca. 300 feet.



It is required to drive the vehicle in a straight line at approximately 1.5 mph before the calibration can be started.

-  -PROCEED
-  -BACK
-  -RETRY
-  -CANCEL



Use the green and yellow arrows to navigate between the different calibration steps. You can cancel the calibration with the red X if needed.



Ensure the calibration has been successful and confirm by pressing the green checkbox.

# Wheel Lock Calibration




The **Wheel lock (Minimum Turn Radius)** calibration determines the minimum turn radius of the vehicle when it is equipped with the eDriveM1 steering controller.




Initiate the calibration process by pressing the **Calibrate** button. Follow the onscreen messaging during the different calibration steps.

During this calibration, the wheels will turn abruptly to the left and the ride-lock position to determine the minimum turning radius of the vehicle.



-  -PROCEED
-  -BACK
-  -RETRY
-  -CANCEL

Use the green and yellow arrows to navigate between the different calibration steps. You can cancel the calibration with the red X if needed.




Ensure the calibration has been successful and confirm by pressing the green checkbox.

**Note:** The calibration can be interrupted at any time by stopping the vehicle.

# Estimate Open-Loop Gain Calibration



The **Estimate Open Loop Gain** calibration is intended to collect important information about the dynamic behavior of the vehicle where the system is installed. It allows the eDriveM1 steering controller to provide the best control performance.




Initiate the calibration process by pressing the **Calibrate** button. Follow the onscreen messaging during the different calibration steps.




Before the calibration can be started, it is important to drive the vehicle at approximately 1.5 mph and center the wheels.

-  -PROCEED
-  -BACK
-  -RETRY
-  -CANCEL



Use the green and yellow arrows to navigate between the different calibration steps. You can cancel the calibration with the red X if needed.




Ensure the calibration has been successful and confirm by pressing the green checkbox.

# Mechanical Play Calibration

**Mechanical Play calibration is used for post calibration steering adjustments and is not required for completion of the calibration.**



The default value of 10 degrees is sufficient for most applications.



Press the **Start Calibration** button.



The MaveriX will display the steps necessary to complete the **Mechanical Play Calibration**. Read the screens for the calibration process, and on the last screen press the green checkmark to begin the calibration process.

- PROCEED
- BACK
- CANCEL

1	2
3	4
5	6

*Continued on next page*

# Mechanical Play Calibration, Continued



After selecting the green checkmark to begin the calibration process, the Calibration screen appears, and the **Start Calibration** button is changed to **Cancel Calibration**.

**Cancel Calibration**

Now that the calibration process has begun, the user will go to the **Job Mode**.



The **Steering Widget** displays with **FP** on the icon, indicating the calibration is active.



*Continued on next page*

# Mechanical Play Calibration, Continued

---



Start a new job on the MaveriX. (For more information on starting a new job, see [Chapter 4, Job Widgets](#)).



Open the **AB Menu** or the **A+ Direction Menu** and set a straight AB guidance path. (For more information on using Guidance, see [Chapter 4, Guidance Menu](#)).



After the AB line is set:

1. Engage the autosteering.
2. Drive at a minimum speed of 6.5 mph (10 kph).
3. Keep speed constant during the entire calibration.
4. While long passes are recommended, the user can disengage and reengage as needed. But it is recommended to stay on a consistent surface.



*Continued on next page*




# Mechanical Play Calibration, Continued

---




During the **Mechanical Play** calibration, the MaveriX system displays popup messages 4 times. All 4 messages are the same:



After the 4<sup>th</sup> message displays, the MaveriX steering system disengages, and the **Calibration Successful** message displays.



Press the green checkmark to confirm the calibration. Then return the Machine menu > Vehicle Calibration screen to view the calibrated values.



If the difference between the new values is more than 5 degrees, the **Mechanical Play** calibration will need to be repeated.

---

# Guidance

---




The **Guidance Menu** is for *development purposes only*.

**Values should not be adjusted.**



# Engage

---




The **Engage Menu** contains settings regarding engaging and disengaging guidance lines.




*Continued on next page*

# Engage, Continued

---



If **Engage** is turned on, it will open an additional extensive menu.



The user can set:


- Maximum speed allowed for engaging on a guidance line.
- Maximum distance allowed for engagement from the guidance line.

Maximum angle allowed to engage on a guidance line.

**Aggressiveness** allows the user to adjust the aggressiveness in which the MaveriX Precision Ag system will attempt to engage on a guidance line. 1 is less aggressive and 10 is the most aggressive.



The **Disengage Sensitivity** should not be adjusted. *It is used for development purposes only.*



# Implements

---




On the **Machines Menu**:

- Select an existing implement for use
- Select an existing implement to edit or delete
- Create a new implement

Swiping left or right will change the highlighted implement. To edit or create a new machine, highlight the desired selection, and press on it.

The highlighted implement will be used in the **Job Menu**.

**Note:** With some vehicle types (example: sprayer), the implement profile is not used. If this vehicle type is selected, the implement section is greyed out.




# Create Implement

---



Click **Create new** to initiate a new implement setup, and the **New Implement Menu** displays.




*Continued on next page*

## Create Implement, Continued

---

### Implement Type

Use the **Implement type** drop-down menu to choose the type to match your machine.




Scroll through the list and click to select the desired implement type:

- Generic Tillage
- Air seeder
- Planter
- Drill
- Sprayer
- Spreader
- Grain cart

**Note:** Depending on the chosen implement type, the displayed 3D implement model will change accordingly. This will also impact the displayed 3D implement model that is displayed on the map during **Job Mode**.

Use the color configuration bar on the left side of the **Implement Setup Menu** to configure the desired color of the vehicle.



The vehicle will change the color accordingly.

**Note:** The vehicle color configuration is optional but is not required to complete the vehicle setup.

---


*Continued on next page*

# Create Implement, Continued

---

## Implement Name

Identify the **Implement Name** area within the UI as shown below.




Double-click the **Implement Name** area to open the keyboard.

**Note:** The **Implement Name** can only contain the following:

- Letters (a-z, A-Z)
- Numbers (0-9)
- Hyphens ( - )
- Underscores ( \_ )
- Spaces

Maximum length of 20-character spaces.

Type the **Implement Name** and press **Done**.



The **Implement Name** is now configured.

*Continued on next page*


# Create Implement, Continued

---

## Implement Model and Year



Repeat the same process to configure the **Implement Model** and **Implement Year**.



**Implement Model** can use any combination of letters, numbers, and symbols up to 8-character spaces.

**Implement Year** requires 4 digits for the year and must be dated between 1900-2099.


**Note:** The **Model** and **Year** configurations are optional, but the **Implement Name** is required to complete the configuration.

## Completing Implement Profile



After the user has entered the information for the **Implement Profile**:

- Click the **Checkbox** button to complete a new **Implement Setup**.
- If the **Implement Setup** is no longer required, it can be canceled with the red X button.



This step completes the **Implement Information** setup.

---




# Implement Information

---



After the **Implement Information setup** has been completed, the below screen displays:



Use the 3 button options on the right side of the screen to complete the following actions:



- Copy current implement profile



- Edit current implement's information, including:

- Name
- Model
- Year
- Color



- Delete current implement.


---

# Implement Dimensions



The **Implement Dimensions Menu** allows users to configure the following measurements specific to each implement and the MaveriX Precision Ag system installation:

- Hitch dimensions
- Axle dimensions
- Implement-specific dimensions
- Implement offset
- Sections and total boom width
- Overlap/skip



*Continued on next page*

# Implement Dimensions, Continued


---

## Entering Dimensions



Double-click the desired dimension to change the setting for the individual vehicle:

- Some measurements will not accept a negative number.
- The box containing the value will be green if the entered value is acceptable. If the entered value is unacceptable as entered, the box will be red.








Push **Enter** to confirm the setting.

**Note:** The system assigns a default dimension to each implement type. It is important for automated steering and application control that the specific machine measurements are entered for each vehicle.

# Measuring Implement Dimensions



When measuring implement dimensions, refer to the **Dimensions** screen for the specific required measurements for each implement type. Any measurement that is vertical is from the ground to the center of the measurement point. Any measurement that is horizontal is center to the center of the measurement points.

	<p>Generic Tillage</p>
	<p>Planter Drill</p>
	<p>Pull-Type Sprayer</p>
	<p>Spreader</p>
	<p>Grain Cart</p>

# Sections

---



In the **Sections** portion of the **Dimensions Menu**, the user can adjust the number of sections and the measurement of the sections. The total boom width is the sum of all the sections measurements.



When the sections' quantity is increased to 3 or more odd number of sections, the left measurement is for the center section, and the right measurement is for both the outside right and left sections. All are added together to achieve the total boom width.



When the sections' quantity is increased to 4 or more even number of sections, the displayed sections are mirrored for the left and right sections. All the sections are added together to achieve the total boom width.

---


## Overlap/Skip

---



Enter a value to drive a pattern where rows intentionally **Skip** or **Overlap**.

When you enter a **Skip** or **Overlap**, the map shows this as an area between swaths in the green coverage lines where a **Skip** is the non-sprayed area between swaths and an **Overlap** is the dark green overlap between swaths.



Use the drop-down box to change between **Overlap** and **Skip**. To enter a value for **Distance**:

- Double-press on the value box to open a number pad for the user to type in the desired value.
- Use the – or + buttons to decrease or increase the value by .1 in for each press.

# Implement Offsets

---



The **left/right implement offset** is the lateral (perpendicular) distance between the center of the implement and the centerline of the vehicle.


When calibrating a **left/right implement offset**, you are compensating for a **physical implement offset**.

To compensate for a **physical implement offset**:

- Measure the effect of the uncompensated implement offset
- Calculate the offset adjustment required
- Enter the calculated adjustment to compensate for the physical implement offset

Calibration is required if the vehicle successfully repeats its passes while driving up and down on a straight A=B line without an implement but shows an offset (skip or overlap) during field work with an implement attached. In this case, the implement is not centered in relation to the vehicle centerline. To compensate for this, complete a **left/right implement offset** calibration for each implement used with MaveriX.

The **left/right implement offset** (for which you will compensate) comprises a measured distance (the amount of the offset) and a direction (left or right of vehicle centerline). In the figure to the left, the offset distance (or amount) is X, and the direction is right. Because it is difficult to measure the **left/right implement offset** on the vehicle/implement combination, you must determine the offset in the field to ensure maximum field work accuracy.



**Note:** Calibration compensates for a static **left/right implement offset** caused by the physical dimensions of the implement. It does not prevent offsets caused by dynamic movements of the implement (such as drift on a slope).

See [Setting the Left/Right Implement Offset - Preferred Method](#) and [Setting the Left/Right Implement Offset - Alternative Method](#) that describe the two ways to determine the left/right implement offset.


---

# Implement Offset – Preferred Method

## Setting the Left/Right Implement Offset – Preferred Method

This method for setting the implement offset is the preferred method because it eliminates the possibility of errors caused by an incorrect vehicle width.

To determine the implement offset:



1. Set an AB guidance path. See [AB Menu](#).

2. Maintaining a speed of 5 kph (3 mph) engage steering and, with good crosstrack and the implement straight, let the system steer you along the guideline for at least 100m. Ensure the implement is in sufficient contact with the ground to leave a visible swath. See Pass 1 in the figure above.

3. Perform a keyhole turn, re-engage the steering, and let the system steer you down the same guideline, again with good crosstrack and with the implement straight. See Pass 2 in the figure to the left.
4. Measure the effect of the uncompensated implement offset shown in the figure to the left (1.00 m in example)—it is the width of the first swath not covered by the second swath.
5. Divide the measurement by two. This is the amount of the physical offset of the implement—the offset you need to compensate for and need to enter as the implement offset in the Implement Configuration screen (see step 7 below)—so 0.5 m in the figure above (and see step 8 below).
6. Determine the direction of the offset—this is the left or right direction of the implement’s centerline relative to the vehicle centerline when viewed in the direction of travel. See the figure above for examples of both a left and right offset.


*Continued on next page*




# Implement Offset – Preferred Method, Continued



7. Navigate to the **Dimensions Menu** (Home > Machines > (implement) > Dimensions), if necessary, scroll down to display the screen below.



8. Enter the left or right implement offset by selecting the **Implement offset** value (displayed at 0 is picture above). This opens a number pad for the user to enter the value in inches. Enter a positive value for a right offset and a negative value for a left offset.
9. Test the completed calibration by letting the system control up and down on a new A=B line. The second swath should overlay the first exactly. If it does not, repeat the calibration.




**Note:** If test results show skips or overlaps after calibrating both the antenna and implement offsets, make sure the implement width is correct.

# Implement Offset – Alternative Method

## Setting the Left/Right Implement Offset - Alternative Method

With this method, instead of driving two passes on the same guideline— one in each direction—drive three passes on adjacent guidelines.

Depending on the direction of your implement offset (left or right), you will get a skip or an overlap on the second pass and the opposite on the third pass.



The amount of skip and overlap will be the same. Either one you choose to measure (2X) divide it in half and enter the result as the implement offset (X) along with the direction of the offset.Implements

**Note:** If the offset were to the right, Pass 2 would produce overlap, Pass 3 would produce skip.

# AC110

Application
Implement Setup
Valve Setup
Sensor Setup
Calibration Values

For both **Vehicle** and **Implement** profiles, the **Application** (AC110) setup is the same process.

Note: The **Application** section is only available if an AC110 is connected to the MaveriX system and powered on.

## Implement Setup

Application
Implement Setup
Valve Setup
Sensor Setup
Calibration Values

In the **Implement Setup** section, the user can set the following options:

- **Tank capacity**
- **Nozzles quantity**
- **Sections delay**
- **Overlap Tolerance**
- **Look ahead**



*Continued on next page*

# Implement Setup, Continued

- Application
- Implement Setup
- Valve Setup
- Sensor Setup
- Calibration Values

- **Tank capacity** – set the amount of product in the tank.
- **Nozzles quantity** – set the total number of nozzles for the boom.
- **Sections delay** –



**On Time** - Enter the number of seconds needed to open the boom valves and build pressure ahead of an unapplied area.

Increase the number to turn on sooner.



**Off Time** - Enter the number of seconds needed to close the boom valves ahead of a previously applied area. Increase the number

to turn off sooner.


- **Overlap Tolerance** - Enter the amount of overlap for entering and existing the headlands.
- **Look ahead** – set the valve advanced time. (*Prescription Maps Only*) (*Future Development*)

# Valve Setup

- Application
- Implement Setup
- Valve Setup
- Sensor Setup
- Calibration Values

In the **Valve Setup** section contains:

- Master valve
- Regulating valve
- Section valve



Continued on next page

- **Master valve** – *used for development purposes only.*
- **Regulating valve** – in this section the user will select the Regulating valve type from the following options:
  - **Motorized Direct** – Two-wire electric motor opens/closes the flow control valve to increase/decrease the application flow rate.
  - **Motorized Inverse** – Two-wire electric motor opens/closes the flow control valve to inversely decrease/increase the application flow rate.
  - **PWM** – Electrohydraulic solenoid valve proportionally increases application flow rate with increased duty cycle (voltage).
  - **PWM Ground** – Electrohydraulic solenoid valve proportionally decreases application flow rate with increased duty cycle (voltage).
  - **PWM 2** – Similar to PWM but with a slower algorithm; use when rate control is too unstable when using PWM.
  - **PWM 2 Ground** – PWM 2 Ground Similar to PWM Ground but with a slower algorithm; use when rate control is too unstable when using PWM Ground.
    - **Positive close (On or Off)** – Turn on for installations where the rate control valve is also used to stop and start product application, for example when no boom On/Off or section valves are present.
- **Section valve** – in this section the user will select the Section valve type from the following options:
  - **Motorized 2 Direct** - electric motorized valve that is:
    - 1) driven open with a positive voltage signal, and
    - 2) driven closed by a negative voltage signal across two signal wires.
  - **Motorized 2 Inverse** - electric motorized valve that is:
    - 1) driven open with a positive voltage signal, and
    - 2) driven closed by a negative voltage signal across two signal wires.
  - **Motor/SOL 1 Direct** - electric motor or solenoid valve that is:
    - 1) driven open with a single positive voltage signal, and
    - 2) returned to a closed position by a spring or other automatic means.
  - **Motor/SOL 1 Inverse** - electric motor or solenoid valve that is:
    - 1) driven closed with a single positive voltage signal, and
    - 2) returned to an opened position by a spring or other automatic means.


---

*Continued on next page*


# AC110 Calibration

Application
Implement Setup
<b>Valve Setup</b>
Sensor Setup
Calibration Values


To Calibrate AC110, first the user will need to setup the Regulating valve type, whether Positive close needs to be on or off, and the Section valve type. It will also require the user to have water in the tank to run calibration. After the information is entered, select the Calibrate button.



The below message will display, to proceed with the calibration of the AC110, press the green arrow, to cancel press the red X or yellow back arrow.



While the system is calibrating, the following screen will be displayed.



**Note:** The calibration process can be canceled at any time by pressing the red X or yellow back arrow.


*Continued on next page*

## AC110 Calibration, Continued




---

- Application
- Implement Setup
- Valve Setup
- Sensor Setup
- Calibration Values

If there is a failure during the calibration process, the following message will display.




Use the buttons to select next step:

-  -CANCEL
-  -RETRY
-  -PROCEED


After a successful calibration is completed the following message will display. Press the green arrow to complete calibration process or the blue arrow to re-run calibration.



# Sensor Setup



The **Master Switch** section is used to select the location of the Master Switch (Internal or AC110).



Internal – If using the Apply widget on MaveriX.

AC110 – If using an External Master switch.



## Spraying flowmeter

Press to display a keypad where you enter a meter calibration value. Locate the meter calibration tag or stamp on the flow meter and the corresponding calibration value.

- For Raven systems, divide the calibration number by 10 and enter this number. For example, if 169 is the calibration value, enter 16.9.
- For TeeJet meters, enter the number as is.
- Many TeeJet meters list the calibration value in pulses/liter. It may be easier to change the units in MaveriX to metric, enter the meter calibration, then change units back to U.S.

## Nh3 Mode

- Set to On for NH3 (anhydrous ammonia) control. Rate will be in lbs. nitrogen/acre (US) or kgs nitrogen/hectare (metric). Volume remaining in tank will be lbs. or kgs of NH3.
- Set to Off to set any other liquid as the application liquid.



# Calibration Values

Application
Implement Setup
Valve Setup
Sensor Setup
<b>Calibration Values</b>

The **Calibration Values** page contains settings and the calibration values from the calibration. See **Table 5-1: Calibration Values Descriptions.**

AC110 parameters	
Valve Advance	0
Reg. Freeze Speed	0 mph
K	
Flow Range	19868
Trigger	1369
Min. PWM	3.0 %
Max. PWM	100.0 %
Meter Calibration	500.0 pl/gal
Manual Reg. Step	0.500
Time Response	
Time Response	8
Min. Flow	0.0 gpm

*Continued on next page*

**Table 5-1: Calibration Values Descriptions**

Name	Description
Valve Advance	<p><i>(Applies to PWM and motorized valves only)</i></p> <p>For PWM and motorized valves you can enter a value to increase the valve position when coming out of headlands. For example, if spray comes on and briefly turns off when coming out of a headland (due to the boom having to recharge) you can enter a Valve Advance value to compensate for this.</p> <p>The range of Valve Advance values is 0 – 20 for PWM and Servo/motorized valves, where:</p> <ul style="list-style-type: none"> <li>• For PWM, 0 – 20 equals 0 – 20% increase from valve’s current position</li> <li>• For motorized, 0 – 20 equals 0 – 2000 ms</li> </ul> <p>When you are no longer applying product (Apply button displays Off or section is Off):</p> <ul style="list-style-type: none"> <li>• For PWM, the system increases the valve’s position by the % you entered</li> <li>• For motorized, the system opens the valve the specified number of ms before it normally opens</li> </ul>
Reg. Freeze Speed	Set the min speed of vehicle and the regulating valve will be held constant and not adjust below this configurable speed.
K	Gain, or how fast the system attempts to hit the target rate.
Flow Range	The maximum flow of the system in pulses.
Trigger	How soon before the target rate the system switches to fine control. (l/min)
Min. PWM	Minimum voltage (percentage) to receive a control valve response.
Max. PWM	Maximum voltage (percentage) to receive a control valve response.
Meter Calibration	The value entered for the Flow Meter’s calibration value.
Manual Reg. Step	The amount (seconds or volts) in manual mode when pressing the increase or decrease buttons on the Rate Option widget. <b>(Note: Servo valve is seconds and PWM valve is volts.)</b>
Time Response	Measure of how quickly the rate control system will react before adjusting the actual rate when it deviates from the target rate.
Min. Flow	Without a Min Flow setting the tips on your sprayer may shut off when flow drops below a certain rate (such as due to a drop in vehicle speed when traveling through a rough spot in the field). The Min Flow value you enter is the flow rate above which MaveriX will continue to spray (apply product) and not close the regulating value completely and will maintain a minimum flow independent of speed and number of sections closed. <b>(continued on next page)</b>

*Continued on next page*

Continued from Table 5-1:


To determine the Min Flow Setting value for your implement:

1. Identify the flow rate at which the spray tips begin to shut off.
  - a. Put the system in Manual mode.



Open the Rate Options widget to display the Product Rate panel, set to Manual, then press the Rate Bump arrows (up arrow increases rate, down arrow decreases rate) to drop the rate until the tips shut off. See [Ch. 4: Widgets](#) for more information.

- b. Identify what the flow value is on the Rate Options widget.



2. Enter a Min Flow Setting value that is slightly higher than the value from the previous step.

Go to the Home Screen > Select the Machines icon > Select the current vehicle or implement > under Application, select Calibration Values > scroll down to Min Flow and double click in box to open number pad > enter value > press the enter key.

---

# Chapter 6: GPS

## Overview

---

**Introduction** This chapter covers the **GPS Menu** on the MaveriX terminal.

---

## Contents


GPS Menu.....	119
GPS Status .....	120
Settings.....	122
NMEA Input .....	122
NMEA Output .....	123
Correction .....	127
SBAS.....	127
Atlas.....	128
RTK Radio.....	129
RTK Radio Detection .....	130
RTK Radio Link .....	132
RTK Radio – RSSI Update .....	135
RTK NTRIP .....	137
RTK NTRIP .....	138
RTK NTRIP Settings .....	139
GPS Log.....	142
Simulator .....	145
Touch Screen Simulator.....	146

---

# GPS Menu

---

## Overview



The **GPS Menu** is used to review and configure all GPS settings for the MaveriX Precision Ag system.

The main sections of the **GPS Menu** are as follows:


- General
- Settings
- Log
- Simulator

Access the **System Menu** from the **Home Screen** to review and configure all the system settings.



Status	Quality indicator	Std. Dev.	Latitude	
General	DGPS (2)	---	-38.3300000	
Settings	Licenses and subscriptions	Correction Type	Longitude	
NMEA	---	---	-58.9100000	
Correction	Expiration	Speed	Altitude	
Log	---	0.0	3.0	
Options	Sats Used	HDOP	Heading	Date
Simulator	10	1.0	270.00	10/05/2018
Options	Diff Age	BER	Time (UTC)	Active session
	2.4 hr.	---	15:40:25	2.0 hr.
	Signals			
	---			

# GPS Status



The **Status** page includes general information about the GPS system status.

It can be reached by following the Home > GPS > Status > General menu.

The **Status** page includes the following information (see Table 6-1 for section descriptions):

Quality indicator		Std. Dev.	Latitude
DGPS (2)		0.64	39.8485591
Licenses and subscriptions		Correction Type	Longitude
20Hz, L2, RTK		SBAS	-95.5621689
Expiration		Speed	Altitude
N/A		0.0	320.5
Sats Used	HDOP	Heading	Date
24	0.6	109.37	01/10/2022
Diff Age	BER	Time (UTC)	Active session
7.0 sec.	0-0	16:39:45	1.4 min.
Signals			
L1, L2, L2C, L5, G1, G2, B1, B2, B3, B2A, B2B, E1B, E5A, E5B, E5AB, QL1, QL2, QL5			
Quality		Station ID	
A, A, A, A, A, A, A, A, A, A, A, A, B, D, D, D		0	
Available Diff		SBAS PRN	
SBAS, RTCM3		138, 131, 133	
Excluded			
ARTK, ATLAS, RTCM2, EDIF, DFX, CMR, RTCM3, ROX, RTCM_23, BEIDOU, ALTPPP, B2BPPP			

*Continued on next page*


**Table 6-1: GPS status page**

Section	Description
Quality Indicator	2 – SBAS 4 – RTK Fix or Atlas Converged 5 – RTK Float or Atlas Converging
Std. Dev.	Standard Deviation – Pseudo-estimate of the DGPS solution accuracy determined as the RMS value of the positional residual errors. Std Dev is valid only if 6 or more satellites are used in the solution calculation.
Latitude	Vehicle’s current latitude position
Licenses and Subscriptions	Active GNSS licenses or subscriptions
Correction Type	Type of differential correction being used— SBAS, ATLAS, or RTK
Longitude	Vehicle’s current longitude position
Expiration	Expiration date of GNSS subscriptions
Speed	Vehicle’s current speed
Altitude	Vehicle’s current altitude
Sats Used	Number of GPS satellites used to calculate the position
HDOP	Horizontal Dilution of Precision
Heading	Vehicle’s current heading in degrees
Date	Current date
Diff Age	Age of the corrections used in the DGPS calculation. Values > 120 seconds require acquiring a new RTK lock. For RTK, the Diff Age is typically 1-2 seconds. For SBAS, the Diff Age is typically 6 to 10 seconds. For Atlas, the Diff Age is typically 10-18 seconds.
BER	Bit Error Rate – Relative strength of the correction satellites. Two numbers are shown separated by a hyphen. The number can be from 0 to 500, with 0 being the best and 500 being the worst.
Time (UTC)	Current UTC time
Active Session	Length of current session
Signals	GNSS signals being used
Quality	Quality of GNSS signals
Station ID	ID of correction station
Available Diff	Differential corrections the receiver is getting
SBAS PRN	Satellites used by SBAS
Excluded	Differential corrections the receiver is not using (excluded from the differential solution)

# Settings

## NMEA Input

---



The **Settings NMEA** page allows users to review and configure the GPS NMEA settings.

It can be reached by following the Home > GPS > Settings > NMEA menu.


The **NMEA Input** screen provides an overview of the connected receiver, the receiver settings, and the received NMEA message.






# NMEA Output

---



The **NMEA Output** screen provides an overview of the NMEA GNSS output of the terminal and the according configuration. This screen can be used to configure the settings to meet the requirements for a third-party controller and/or implement.

It can be reached by following the Home > GPS > Settings > NMEA menu and scrolling down.



The **NMEA Output** screen controls the output settings for the COM2 (050-0041-01) output. See [Maverix Cable Diagram](#), for cable options.



---

*Continued on next page*


# NMEA Output, Continued

## Terminal Connection & Baud Rate Settings

Identify the terminal connection and baud rate settings within the **Output Menu**.



Use the drop-down menu to select the desired **terminal connection**.



Highlight to select the desired **baud rate** from the drop-down menu.



Baud rate values available in drop-down:


- 4800
- 9600
- 19200
- 38400
- 57600
- 115200

*Continued on next page*

## NMEA Output, Continued

### NMEA Output Configuration

The **NMEA Output configuration** screen allows users to set the desired frequency for the following NMEA output messages.



Message	Description
GGA	GPS position data (latitude, longitude, number of satellites used, age of differential corrections, etc.)
GLL	Latitude and longitude data
VTG	Course-over-ground and ground speed
GSV	GNSS satellites in view
RMC	Contains recommended minimum specific GNSS data (latitude, longitude, ground speed, navigational status, etc.)
GSA	GPS DOP and active satellite information
ZDA	UTC time and date information
GST	GNSS pseudo range error statistics and position accuracy
Diff	Turn RTCM3 messages on or off

**Note:** If the MaveriX has a fully calibrated and powered eDrive connected, this NMEA output is roll corrected. To verify, the below image would display on the status bar.





*Continued on next page*

# NMEA Output, Continued


---

## NMEA Messages

Choose the desired NMEA message and activate it by clicking the **Enable** button. After a message type is enabled, the button shows a green checkmark.



Click on the **Frequency** window to configure the message rate for the desired NMEA message.



Click the drop-down list to select the desired frequency in Hz.

Available frequencies include:


- 0.1 Hz
- 0.2 Hz
- 0.5 Hz
- 1 Hz
- 2 Hz
- 5 Hz
- 10 Hz
- 20 Hz

---

*Continued on next page*

# Correction


## SBAS



The **Settings Correction** page allows users to review and configure the correction for the GPS receiver of the MaveriX Precision Ag system.

It can be reached by following the Home > GPS > Settings > Correction menu.

The default correction setting is **SBAS** (required for WAAS (NA) or EGNOS (EU) corrections).



Click the current setting (**SBAS**) in the **Correction Menu** and select the desired **GNSS correction** from the drop-down menu.




Atlas


RTK

# Atlas

---




When the **Atlas Correction source** is selected, it enables the receiver to use the Hemisphere GNSS Atlas L-band correction service.




**Note:** The Atlas frequency and baud rate are automated settings performed by the GNSS receiver depending on its position.

# RTK Radio

---



If the **RTK Radio Correction source** is selected, the default RTK setting is to support an external radio.



The **RTK Radio Correction setting** performs the following functions:


- Detects a connected radio
- Queries the radio link
- Updates the RSSI readings of the radio

---


*Continued on next page*

# RTK Radio Detection


---



Press the **Detect Radio** button to initiate the radio detection. This step must be completed before the **Radio Link Configuration** becomes available.



Press the green arrow to start **Radio Detection**.




*Continued on next page*





## RTK Radio Detection, Continued

---




If radio detection is successful, the following screen will be displayed:



Press the green checkmark to proceed, radio detection completed.

If the radio detection fails, the following screen displays:




Press the blue arrow to retry radio detection, or the red X to cancel.

---

# RTK Radio Link


---



Press the **Radio Link** button to open **Radio Link Configuration**. (Complete **Radio Detection** steps first.)




## Radio Link - Radio Channel




- Double-click the entry field to type in the required radio channel.
- Click the green arrow to move to the next setting.

---

*Continued on next page*



## Radio Link – Mode



- PROCEED
- BACK
- CANCEL

- Click the entry field to open the drop-down menu
- Select the required radio mode

SLOW


SLOW2



- Click the green arrow to move to the next setting


---

*Continued on next page*




- PROCEED
- BACK
- CANCEL


### Radio Link – Apply Changes




- Press the green arrow to apply changes to the radio.
- The below image displays while the radio is being configured.



- When the radio is successfully configured, the below image will be displayed.
- Press the green checkmark to return the **GPS Settings**.



# RTK Radio – RSSI Update



**RSSI - Received Signal Strength Indicator** -the actual power in the received radio signal (in dBm).




**Note:** GPS will be lost during an RSSI update.

Press the green arrow to initiate the **RSSI update**.




- PROCEED
- RETRY
- CANCEL

Wait for the **RSSI** to update.






*Continued on next page*

# RTK Radio – RSSI Update, Continued



When a successful **RSSI Update** is completed, the below screen displays, confirming the update and the new **RSSI value**. Press the green arrow to return to **GPS Settings**.




-  -PROCEED
-  -RETRY
-  -CANCEL

If the **RSSI Update** fails, the below image displays. Press the blue arrow to retry the update or the red X to cancel.



# RTK NTRIP


---




To review and configure the **NTRIP setting**, adjust the **RTK Settings Menu** to **NTRIP Settings**.




Click on the **RTK Settings Menu** and select **NTRIP Settings** from the drop- down list.



# RTK NTRIP



To view the **RTK NTRIP** settings press the **View/Edit** button:



Press the **View/Edit** button to review and configure the following NTRIP settings:


- Server Address
- Port
- Mount Point
- User ID
- Password

The bottom button will either display **Start** or **Stop**.



- If **Start** is displayed, the **NTRIP** corrections are not being used.
- If **Stop** is displayed, the MaveriX system is using the supplied **NTRIP** corrections.
  - The Rx and Tx in the bottom-left corner can be used to verify the data transfer is accruing.



# RTK NTRIP Settings




## NTRIP Settings – Server Address




- Double-click the entry field to type in the required **Server Address**.
- Click the green arrow to move to the next setting.

## NTRIP Settings - Port




- Double-click the entry field to type in the required **Port** number.
- Click the green arrow to move to the next setting.


*Continued on next page*




**NTRIP Settings – Mount Point**



- Double-click the entry field to type in the required **Mount Point**.
- Click the green arrow to move to the next setting.




**NTRIP Settings – User ID**







- Double-click the entry field to type in the required **User Id**.
- Click the green arrow to move to the next setting.

*Continued on next page*




**NTRIP Settings – Password**



-  -PROCEED
-  -BACK
-  -CANCEL

- Double-click the entry field to type in the required **Password**.
- Click the green arrow to move to the next setting.


**NTRIP Settings – Accept to apply changes**



- Click the green arrow to accept and apply the entered changes.
- Click the red X to cancel the configuration.

# GPS Log


---




The **Log Options** page allows users to review and configure the option to create data logs of the GPS receiver with the MaveriX Precision Ag system.

It can be reached by following the Home > GPS > Log > Options menu.

By default, the GPS data logger is turned off.



Click the **Logger** switch to turn the GPS data logging function on. The system is now ready to start a GPS log.



---


*Continued on next page*

## GPS Log, Continued


---

### Create an Automatic Log

Press the **Start log** button to start a GNSS data log. By default, the system generates an automatic file name. The **Making log** message verifies that a GPS log is being generated.



Press the red X button to finalize the data log.




**Note:** The GPS data log can be managed and exported per the **Files Menu**. See [Chapter 8, USB Transfer](#) about this procedure.

---


*Continued on next page*

## Create a Manual Log

If it is required to use a file name that differs from the automatically generated name, click to set the file name generation to **Manual**.




The green checkmark changes to indicate the current setting.



Click in the window with the log file name to type the desired file name before generating the log.


Press the **Start log** button to start a GPS data log. The **Making** message verifies that a GPS log is being generated.



Press the red X button to finalize the data log.

**Note:** The GPS data log can be managed and exported per the **Files Menu**. See [Chapter 8, USB Transfer](#) about this procedure.

# Simulator



**WARNING: The MaveriX Simulator should be used only for demonstrations and development use.**

The **Simulator Options** page provides the user the option to configure and use the integrated **GNSS simulator** of the MaveriX Precision Ag system.


It can be reached by following the Home > Simulator > Options menu.

The **GNSS simulator** is off by default. To turn on the **GNSS simulator**, use the **Simulator** switch.




The **Simulator** options are as following:

- Log (*not supported, development testing only*)
- ESI2 (*not supported, development testing only*)
- USB Controllers (*not supported, development testing only*)
- Touch Screen




To turn on the **Touch Screen Simulator**, select the button next to **Touch Screen**. The button turns green when the simulator is active.




# Touch Screen Simulator


---



To use the **Touch Screen Simulator**, from the **Job** screen, press the **GPS Widget** twice.



- The first press opens **GPS information**




- The second press opens **Simulator options**.



*Continued on next page*








To control the speed of the simulator, use the left slider bar.



**Speed** can also be entered in by double-clicking on the **Speed**, then typing in the desired **Speed**.



To control the **Wheel angle** (steering) of the simulator, use the right slider bar.



The **Reset** button can be used to bring the steering back to center.



The AZ in the top right-hand corner stands for **Automatic Zero**.



- If the box is checked next to **AZ**, then the steering will automatically return to center.



- If unchecked, the steering will remain in the last set position.

# Chapter 7: Diagnostic

## Overview

---

**Introduction** This chapter contains information about the **Diagnostic Menu** on the MaveriX terminal.

---


## Contents

Diagnostic Menu .....	149
GNSS .....	150
GPS Menu .....	150
Receiver .....	152
RTK Status .....	153
Subscriptions .....	155
Update .....	155
Terminal .....	156
Information .....	156
Review .....	157
Records .....	158
ESi2 .....	159
Information .....	159
AGS .....	159
Steering Test .....	160
Wheel Control Test .....	160
eDrive .....	161
Information .....	161
Events .....	162
Status Menu .....	162
Configuration Menu .....	162
Update .....	163
AC110 .....	164
Information .....	164
Ports .....	165
Update .....	165
Logs .....	165

---

## Diagnostic Menu


---



The **Diagnostic Menu** is used view diagnostic information, upgrade firmware, and validate communication on the MaveriX Precision Ag system.

Sections in the **Diagnostic Menu** include:

- GNSS
- Terminal
- ESI2
- eDrive
- AC110
- Logs...




# GNSS



The **GNSS Menu** contains information for the **GNSS antenna**.

# GPS Menu



The **GPS Menu** contains all information shown below. See the [GPS Status table](#) for definitions.


GPS Status	
GNSS Subscriptions	RTK, 20Hz
ATLAS Expiration Date	N/A
Correction Type Used	RTCM3
Standard Deviation	0.010
Diff Age	1
BER	0-0
Signal Strength (L-band)	93
Signals	L1,L2,L2C,L5,G1,G2,B1,B2,B3,B2A,B2B,E1B,E5A,E5B,E5AB,QL1,QL2,QL5
SNR	A,A,A,A,A,A,A,A,A,A,A,A,C,D,D,D
Satellites Used	5,5,0,4,6,6,7,1,7,0,6,6,6,0,0,0,0
L-band frequency	1545.9150
L-band baudrate	600
Status	RTK fixed (4)
Station ID	333
SBAS PRN	138,131,133
Available Diff	SBAS, ATLAS, RTCM3
Excluded	SBAS, RTCM2, EDIF, DFX, CMR, RTCM3, ROX, RTCM_23, BEIDOU, ALTPPP, B2BPPP
Rover Slip Flag	0
Base Slip Flag	1
Scintillation (Ionospheric)	0
Distance to base [ft]	328.08
ARM Status (ArmStat)	7F
NAVCON	599999

*Continued on next page*

**Table 7-1: GPS Status**

Section	Description
GNSS Subscriptions	Active GNSS subscriptions
ATLAS Expiration Date	Expiration date of current Atlas correction. Will display as date if subscribed, "N/A" if not subscribed/expired
Correction Type Used	Type of differential correction being used
Standard Deviation	Pseudo-estimate of the DGPS solution accuracy determined as the RMS value of the positional residual errors. Std Dev is valid only if 6 or more satellites are used in the solution calculation.
Diff Age	Age of the corrections used in the DGPS calculation. Values > 120 seconds require acquiring a new RTK lock. For RTK, the Diff Age is typically 1-2 seconds. For SBAS, the Diff Age is typically 6 to 10 seconds. For Atlas, the Diff Age is typically 10-18 seconds.
BER	Bit Error Rate – Relative strength of the correction satellites. Two numbers are shown separated by a hyphen. The number can be from 0 to 500, with 0 being the best and 500 being the worst.
Signal Strength (L-band)	Signal Strength of the Atlas L-Band correction signal. The value can range from 0 to 99, with 0 indication no signal and 99 being the highest strength.
Signals	GNSS signals being used
SNR	Quality of GNSS signals
Satellites Used	Number of GPS satellites used to calculate the position
L-band frequency	Frequency used for L-band correction
L-band baud rate	Data rate for L-Band service (preset configuration that does not change during operation)
Status	2 – SBAS 4 – RTK Fix or Atlas Converged 5 – RTK Float or Atlas Converging
Station ID	ID of correction station
SBAS PRN	Satellites used by SBAS
Available Diff	Differential corrections the receiver is receiving
Excluded	Differential corrections the receiver is not using (excluded from the differential solution)
Rover Slip Flag	Indicator for potential receiver jamming or other reception issues (non-zero indicates issue)
Base Slip Flag	Same as Rover Slip Flag, only applies if receiver is used as RTK base
Scintillation (Ionospheric)	Indicator for ionospheric scintillation. 0 (little or no scintillation – does not adversely affect RTK solution) 1-100 (scintillation detected – adversely affects RTK solution)
Distance to base [ft]	Distance between base and rover
ARM Status (ArmStat)	<i>For troubleshooting purposes only</i>
NAVCON	<i>For troubleshooting purposes only</i>

# Receiver



The **Receiver Menu** contains information about the GNSS receiver. See the table below the image for definitions.

Receiver Status	
Receiver	A631
Applications	MFA, MFA
GPS Firmware	6.0Aa04a
GLONASS State	Enabled
Serial Number	99903103
Active	1
Bootloader	162
GNSS Out	GPS, GLONASS, GALILEO, BEIDOU, QZSS
Fleet	20
HW Version	1
Production Date	06/19/2020

**Table 7-2: Receiver Status**

Section	Description
Receiver	Type of receiver
Applications	Available applications
GPS Firmware	GPS firmware version
GLONASS State	State of GLONASS subscription, where value is one of the following: <ul style="list-style-type: none"> <li>• Enabled (valid subscription entered)</li> <li>• Disabled (no subscription entered)</li> </ul>
Serial Number	ESN of the receiver
Active	<i>For troubleshooting purposes only</i>
Bootloader	Current boot loader version (used to update the firmware)
GNSS Out	Shows if outputting GNSS information in NMEA messages
Fleet	<i>For troubleshooting purposes only</i>
HW Version	Hardware version of receiver
Production Date	Manufacturing date of receiver

# RTK Status

---



The **RTK Status Menu** contains information on RTK. See Table 7-3 for definitions.

RTK Status	
Active Mode	RTK
Base Latitude	39.8479167
Base Longitude	-95.5622421
Base Altitude	324.579
Distance to Base	0.00 m
Heading to Base	0.00 deg
Diff Age	1
Station ID	333
Radio Type	p400
Radio Frequency	-
Channel	63
Region Code	3
RSSI	-59 dBm

---

*Continued on next page*

**Table 7-3: RTK Status**

Section	Description
Active Mode	User-selected correction type
Base Latitude <sup>1</sup>	Latitude of the base station in decimal degrees
Base Longitude <sup>1</sup>	Longitude of the base station in decimal degrees
Base Altitude <sup>1</sup>	Ellipsoidal height of the base station
Distance to Base <sup>1</sup>	Distance between base and rover
Heading to Base <sup>1</sup>	Angle of heading to base station
Diff Age	Age of the corrections used in the DGPS calculation. Values > 120 seconds require acquiring a new RTK lock. For RTK, the Diff Age is typically 1-2 seconds. For SBAS, the Diff Age is typically 6 to 10 seconds.
Station ID	Base station ID
Radio Type <sup>1, 2</sup>	Radio type in the rover receiver
Radio Frequency <sup>1, 2</sup>	<i>This is for future development only, not currently supported.</i> Frequency you entered when setting up your radio; it is the same frequency you entered on your base station radio
Channel <sup>1, 2</sup>	<i>This field appears only if you have a 920 MHz radio connected.</i> Channel you entered when setting up your radio; it is the same channel you entered on your base station radio.
Region Code <sup>1, 2</sup>	<i>This field only appears if you have a 920 MHz radio connected and is used for troubleshooting purposes only</i>
RSSI <sup>1, 2</sup>	Received signal strength indicator - actual power in the received radio signal (in dBm).


<sup>1</sup> Only appears if correction type is set to **RTK**.

<sup>2</sup> Only appears if **Detect Radio** is activated. See [Chapter. 6 GPS](#) for more information.



# Subscriptions

---



The **Subscriptions Menu** contains information associated with GNSS subscriptions.



**GNSS Serial Number** – is the receiver’s Electronic Serial Number (ESN).


**Atlas Expiration Date** – displays the expiration date of the current Atlas subscription, or **00/00/2000** if no Atlas subscription is active.

**GNSS Subscriptions** – lists all **GNSS** subscriptions on the receiver.

---

# Update

---



The **Update Menu** is for future development and is currently unsupported.



# Terminal

---




The **Terminal Menu** contains information associated with the MaveriX terminal.

---

# Information

---



The **Information Menu** contains information associated with the MaveriX terminal, shown below.

**Terminal**

Model	SN	ESN	Software
---	---	---	v1.4

**ECU status**

Module temperature 23 °C


**CAN status - CAN 0**

Item	Value	Refresh
RX - Bus Status	-	
Error counter	-	
Historical max	0	🔄
<b>TX - Bus status</b>		
Error counter	-	
Historical max	0	🔄


**CAN status - CAN 1**

Item	Value	Refresh
RX - Bus Status	-	
Error counter	-	
Historical max	0	🔄
<b>TX - Bus status</b>		
Error counter	-	
Historical max	0	🔄

# Review




The **Review Menu** is used for future development and is currently unsupported.




# Records

---



The **Records** section of the **Terminal Diagnostics** is used for log recording; and can be used for either CAN or GPS logging.

CAN	GPS
	



**CAN 0** – is used for logging **Terminal, AC110** and **Steering** logs.

**CAN 1** – is for future development.

**GPS** – is used for logging **GPS logs**.

To create a log:

- Press the **Start** button.
- A message displays with the name of the log file.
- Press the **Stop** button when the log is complete.
- Select the log file from the drop-down menu.
- Press the **Export** button.

**Note:** For more information on working with **Files**, see [Chapter 8: Files](#), on [File Management](#).

## ESi2

---




The **ESi2 Menu** contains information associated with the ESi2.


---

## Information

---




The **ESi2 Information Menu** displays information from the ESi2.

ESi2 Speed				
	Serial number	Manufacture date	Hardware	Software
	896561574	16/11/2020	0-34	1.73
ECU status				
Module temperature				21 °C
Battery voltage				13.0 V
Control Mode				Speed

---

## AGS

---



The **AGS (Autoguide Status) Menu** is for development use only.

Autoguide Status (AGS)	
Pilot License	Available
(P70) General Status	READY FOR ENGAGE (0)
(P71) Error Code	NO ERROR (0)

---

# Steering Test

---



The **Steering Test Menu** contains the diagnostic steering test.




The **Output** selection has a drop-down with 2 options:


1. Steering Test (default)
  2. User Override (*development use only*)
- 

# Wheel Control Test

---



The **Wheel Control Test Menu** is for development use only.



# eDrive

---



The **eDrive Menu** contains information associated with the eDriveM1.

---

## Information

---




The **eDrive Information Menu** contains information pertaining to the **eDriveM1**, shown below.

The screenshot shows the eDrive Information Menu with the following data:

eDrive				
	Serial number	MFG date	Hardware	Software
	---	---	---	---
<b>ECU status</b>				
Module temperature				-
Battery voltage				-
Capacitor voltage				-
<b>CAN status - CAN 0</b>				
RX - Bus Status				
Error counter				-
Historical max			0	
TX - Bus status				
Error counter				-
Historical max			0	
<b>CAN ESI2 status</b>				
RX - Bus Status				
Error counter				-
Historical max			0	
TX - Bus status				
Error counter				-
Historical max			0	

## Events

---



The **Events Menu** contains error messages from the **eDriveM1**. This is for troubleshooting use.

---

## Status Menu

---




The **Status Menu** displays information from the eDriveM1, to be used for troubleshooting.

The **Status Menu** continually updates all readings.

---

## Configuration Menu

---



The **Configuration Menu** displays information from the eDriveM1, to be used for troubleshooting.


The **Configuration Menu** requires user to press the **Read** button at the top of the page to start displaying the information.

---




# Update

---



The **Update Menu** allows the user to update the firmware in the **eDriveM1**.



# AC110

---




The **AC110 Menu** contains information associated with the AC110.

---

## Information

---



The **AC110 Information Menu** contains information pertaining to the **AC110**, shown below.

A screenshot of the AC110 Information Menu. The menu is displayed on a dark background with white text. At the top, it shows 'AC110' with a small icon of the hardware unit. Below this is a table with four columns: Serial number, MFG date, Hardware, and Software. The values are: Serial number 1, MFG date 15 / 2, Hardware 15.1.1, and Software 3.1.6 b01. Below the table are three sections: ECU status, CAN status, and TX - Bus status. Each section contains several rows of data, including Module temperature, Battery voltage, Capacitor voltage, RX - Bus Status, Error counter, and Historical max. The RX - Bus Status and TX - Bus status sections also include a refresh icon (a circular arrow) next to the Historical max value.

Serial number	MFG date	Hardware	Software
1	15 / 2	15.1.1	3.1.6 b01

**ECU status**

Module temperature	24 °C
Battery voltage	13.4 V
Capacitor voltage	13.3 V

**CAN status**

RX - Bus Status	Ok
Error counter	0
Historical max	0
TX - Bus status	Ok
Error counter	0
Historical max	0

## Ports

---



Under the **Ports** section, the **Inputs** and **Outputs** pages are used for troubleshooting and diagnostics.


---

## Update

---




The **Update Menu** allows the user to update the firmware in the **eDriveM1**.



## Logs

---



The **Logs Menu** contains error messages from the MaveriX system. This is for troubleshooting use.

---

# Chapter 8: Files

## Overview

---

**Introduction** This chapter details working with different file types in the **Files Menu**.

---


## Contents

File & Data Management .....	167
File Browser .....	168
File Types .....	169
File Sorting.....	170
USB Transfer.....	171
Deleting Files .....	173
Job Summary .....	175

---


# File & Data Management

---




The **Files Menu** is used to manage data files on the MaveriX Precision Ag system. Users can review, import, and export different supported file types.

Access the **Files Menu** from the **Home Screen** to review and configure all system settings.




# File Browser

---



The main browser view consists of the following:

- MaveriX Terminal data (left side)
- USB Drive data (right side)
- File organization and transfer (middle)




Click the **refresh button** to show the latest status of available data files on either the MaveriX terminal or the USB drive connected to the terminal.

Click the **refresh button** to update the file status.



# File Types



The default file type is the **Map file**. Press the map file symbol (under the **Refresh** button) to open the file type selector.


Use the **File Type** selector to choose the **File Type** shown and managed per the file browser.



Icon	Description	Icon	
	Map		Widget Configurations
	Machines		GPS Logs
	Prescriptions		CAN Logs
	Updates		Activations
	Profiles		Screenshots
	Configurations		

# File Sorting


---



The **File Sorting** selector allows the user to choose the sorting method for the different file types. The standard **File Sorting** method is by **Job**. Press the button to open the **File Sorting** selector.






Choose the desired sorting method by pressing the corresponding symbol.



Once the configuration has been made, the files will be re-sorted within the file browser.


**Table 8-1: File Sorting Icons**

Icon	Description
	Sort by Job
	Sort Alphabetical
	Sort by Date



# USB Transfer

---




The **File Transfer** between the MaveriX Precision Ag terminal and a **USB** drive is established with the following steps.

1. Connect a **USB** flash drive to the terminal. It will be automatically detected by the terminal and the file browser display as follows:




2. Choose the desired **File** type.




---



*Continued on next page*



3. Highlight and select the desired **File** to be transferred.




4. Click the blue transfer arrow to transfer the **File** to the **USB** flash drive. Click the orange transfer arrow to transfer from the **USB** to the terminal.





## Deleting Files


---



To delete a **File**, highlight and select the desired **File**.



Click the  button to open the **Delete** button.




Select the  button.


---


*Continued on next page*

# Deleting Files, Continued


---




After selecting the  button, the following confirmation screen displays.




Select the green checkmark to confirm deletion. Select the red X to cancel.




# Job Summary



To get a **Job Summary** report for a job, you will first need to export the **Job(s)** onto a **USB** thumb drive. Take the **USB** and open the files on a computer.




Open the folder labeled: (your job name)\_shape. In the image above it is: ABC Steer guide\_shape




Open or save the PDF.

*Continued on next page*



Below are images of a **Job Summary**:



# Chapter 9: System

## Overview

---

**Introduction** This chapter explains the **System Menu** and settings.

---

## Contents

System Menu .....	178
General .....	179
Information.....	179
International.....	181
Interface .....	184
Screen.....	184
Sound.....	187
Touch.....	189
Wireless.....	192
Wi-Fi .....	193
Activations.....	195
Licenses .....	195
Subscriptions .....	195
Enter Code .....	196
Registration .....	197
Downloads Menu .....	197
System.....	198
Updates .....	198
Plugins .....	200

---

# System Menu


---



The **System Menu** is used to review and configure all system settings for the MaveriX Precision Ag system. The main sections of the **System Menu** are as follows:

- General
- Interface
- Wireless
- Activations
- System
- Plugins


Access the **System Menu** from the **Home Screen** to review and configure all system settings.





# General

## Information



The **Information** page includes general information about the system and the status.

It can be reached by following the Home > System > General > Information menu.




The **General information** of the MaveriX terminal is listed here:


A screenshot of the 'General' information section, showing a list of system statistics:

Category	Value
Current available map	100.0%
Stored maps	10
Storage	11G
Free space	11G
Software version	0.1
Operation time	1:57 h
Hardware model	PMA
Serial number	0000
Hardware ID	cfcd03048f6329b5e1cc2


*Continued on next page*




You can see the **WiFi information** displayed here:



You can see the **Software information** on this screen:




The **Historical information** can be found here:



# International

---



The **International Menu** allows the user to review and adjust the current settings for **Language**, **Units of measure**, and **Time zone** according to location.




---


*Continued on next page*

# International, Continued

---




To adjust the **language**, use the arrows to scroll in the **Language** window.



A scroll bar opens that allows the user to choose the desired **language** from a list of supported languages. The selected **language** is highlighted in green.




If the **language** setting has been changed, a reboot of the terminal is required to complete the new configuration.




---


*Continued on next page*




To adjust the **Units of Measure** setting, use the arrows to scroll in the **Units of Measure** window.



A scroll bar opens that allows the user to choose the desired **Unit of Measure** from a list of supported units. The selected **Unit of Measure** is highlighted in green.



To adjust the **Time Zone** setting, use the arrows to scroll in the **Time zone** window.




A scroll bar opens that allows the user to choose the desired **Time Zone** from a list of supported **Time Zones**. The selected **Time Zone** is highlighted in green.




# Interface

## Screen



The **Screen** menu allows the user to review and configure the settings for the screen brightness and the screenshot function.


The **Screen** page can be reached by following the Home > System > Interface > Screen menu.




*Continued on next page*

## Screen, Continued


---




Click on the button slider to adjust the brightness of the screen from low (left) to high (right).




**Status Bar** is used for *development purposes only*.



**3D Graphics** is used for *development purposes only*.




**OFF and Screenshot** buttons is for *development purposes only*.



---

*Continued on next page*




The **OFF** and **Screenshot** buttons are for development purposes only, but the screenshot function can be used.

The **Screenshot** function allows the user to take screenshots of the current User Interface (UI). This feature can be helpful for record keeping or trouble shooting with customer service.

There are two ways to take a screenshot:

- a. Double-press the power button
- b. Enable the **OFF** and **Screenshot** buttons and select the **SCR** button from **Status Ribbon**.

When a successful screenshot is taken, using either method, a message will temporarily be displayed on the screen with the name of the screenshot:




**Note:** Screenshot files are saved in the **Files Menu** of the MaveriX Precision Ag terminal and can be exported to a USB drive for transfer. See [Chapter 8: Files](#) for more information.




# Sound

---



The volume for sounds related to **General**, **System**, **Alerts**, and **Multimedia** can be adjusted in this menu.

Navigate to the Home > System > Interface > Sound menu.




---


*Continued on next page*

## Sound, Continued


---



Click the slider button to adjust the **Sound** volume from low (left) to high (right).




The **Silence** button can be used to mute the sound level completely. If the **Silence** button is pressed, a red checkmark appears, and the volume bar changes color from green to grey.



# Touch

---



The **Touch Menu** allows the user to review the touch screen functionality.

It can be reached by following the Home > System > Interface > Touch menu.

The **Touch Menu** includes two main functions: **Draw** and **Pinch**.




---

*Continued on next page*

## Touch, Continued


---



Use the **Draw** button to activate the draw function for the touchscreen.



Once the **Draw** function has been activated, move your finger across the screen and notice the tracks marked with red dots.




Finalize the **Draw** function by pressing the **Exit** button at the lower-right corner of the screen.

---

*Continued on next page*

## Touch, Continued

---



You can adjust the size of the tractor on the screen using a pinching motion on the touch screen.

Click the **Pinch** button to use the **Pinch** function for the touch screen.



Once the **Pinch** function has been activated, use the press and hold technique to move the tractor across the screen.




Finalize the **Pinch** function by pressing the **Exit** button at the lower-right corner of the screen.

---

# Wireless

---




The **Wireless** menu allows the user to review and configure the **Wireless** functionality of the MaveriX terminal application. It can be reached by following the Home > System > Wireless menu.

The **Router Menu** is for development use only.


The **Wi-Fi Menu** is used to manage network connections.

The **Tools Menu** is for development use only.

# Wi-Fi



Use the **Network Off/On** switch to enable the **Wi-Fi** functionality.




The **Automatic Mode** setting allows the MaveriX terminal to automatically search for network signals. **Automatic Mode** is on by default and should not be turned off.


The **Automatic Connection** setting allows the MaveriX terminal application to automatically connect to known networks when they are available.

*Continued on next page*


## Wi-Fi, Continued



To connect to a **WiFi network**, the user selects from a list of available networks by selecting on the network name.



Type the appropriate password by pressing inside the white box. This will open a keypad. Confirm with the green checkmark button within the **Enter** password window. (To cancel, press the red X)






# Activations

## Licenses

---




The **Activations** section is used to manage the activations and subscriptions of the MaveriX terminal application. The **Activations** page can be reached by following Home > System > Activations menu.


The **Licenses Menu** is left blank and is for future development.

---


## Subscriptions




The **Subscriptions Menu** is for future development use and is currently unsupported.



# Enter Code




To enter a new **Activation Code**, double-click the **Enter Activation Code** window.




Type the **Activation Code** and confirm your entry by pushing the **Done** button.

Push the **Send code** button to submit the **Activation Code**.




# Registration

---




The **Registration** is for future development and is not currently supported. To register your product, please contact your Outback Dealer or Outback Customer Service.




# Downloads Menu

---




The **Downloads Menu** is for future development use only and is currently unsupported.




# System

## Updates



The **System Updates** page is used to manage the firmware version of the MaveriX terminal application.


It can be reached by following the Home > System > Updates menu.




*Continued on next page*

# Updates, Continued


---




Review the current version of software that is installed to the system.



Update the software by using a **USB** drive.



Initiate a software update over Wi-Fi. *Future development, currently unsupported.*



**Note:** The remote update requires an internet connection to the terminal through a WiFi interface. [See Chapter 9: System, Wireless for Wi-Fi connections.](#)

Software downgrades must be enabled by activating the downgrade switch.




**Note:** Software downgrades are disabled by default.


---

# Plugins

---



The **Plugins Menu** is password protected and is only accessible by developers.



---

# End User License Agreement

---

**IMPORTANT** - This is an agreement (the "**Agreement**") between you, the end purchaser ("**Licensee**") and Hemisphere GNSS Inc. ("**Hemisphere**") which permits Licensee to use the Hemisphere software (the "**Software**") that accompanies this Agreement. This Software may be licensed on a standalone basis or may be embedded in a Product. Please read and ensure that you understand this Agreement before installing or using the Software Update or using a Product.

In this agreement any product that has Software embedded in it at the time of sale to the Licensee shall be referred to as a "**Product**". As well, in this Agreement, the use of a Product shall be deemed to be use of the Software which is embedded in the Product.

BY INSTALLING OR USING THE SOFTWARE UPDATE OR THE PRODUCT, LICENSEE THEREBY AGREES TO BE LEGALLY BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, (I) DO NOT INSTALL OR USE THE SOFTWARE, AND (II) IF YOU ARE INSTALLING AN UPDATE TO THE SOFTWARE, DO NOT INSTALL THE UPDATE AND PROMPTLY DESTROY IT.

HEMISPHERE PROVIDES LIMITED WARRANTIES IN RELATION TO THE SOFTWARE. AS WELL, THOSE WHO USE THE EMBEDDED SOFTWARE DO SO AT THEIR OWN RISK. YOU SHOULD UNDERSTAND THE IMPORTANCE OF THESE AND OTHER LIMITATIONS SET OUT IN THIS AGREEMENT BEFORE INSTALLING OR USING THE SOFTWARE OR THE PRODUCT.

1. **LICENSE.** Hemisphere hereby grants to Licensee a non-transferable and non-exclusive license to use the Software as embedded in a Product and all Updates (collectively the "**Software**"), solely in binary executable form.
2. **RESTRICTIONS ON USE.** Licensee agrees that Licensee and its employees will not directly or indirectly, in any manner whatsoever:
  - a. install or use more copies of the Software than the number of copies that have been licensed;
  - b. use or install the Software in connection with any product other than the Product the Software was intended to be used or installed on as set out in the documentation that accompanies the Software.
  - c. copy any of the Software or any written materials for any purpose except as part of Licensee's normal backup processes;
  - d. modify or create derivative works based on the Software;
  - e. sub-license, rent, lease, loan or distribute the Software;
  - f. permit any third party to use the Software;
  - g. use or operate Product for the benefit of any third party in any type of service outsourcing, application service, provider service or service bureau capacity;
  - h. reverse engineer, decompile or disassemble the Software or otherwise reduce it to a human perceivable form;
  - i. Assign this Agreement or sell or otherwise transfer the Software to any other party except as part of the sale or transfer of the whole Product.
3. **UPDATES.** At Hemisphere's discretion Hemisphere may make Updates available to Licensee. An update ("**Update**") means any update to the Software that is made available to Licensee including error corrections, enhancements and other modifications. Licensee may access, download and install Updates during the Warranty Period only. All Updates that Licensee downloads, installs or uses shall be deemed to be Software and subject to this Agreement. Hemisphere reserves the right to modify the Product without any obligation to notify, supply or install any improvements or alterations to existing Software.
4. **SUPPORT.** Hemisphere may make available directly or through its authorized dealers telephone and email support for the Software. Contact Hemisphere to find the authorized dealer near you. As well, Hemisphere may make available user and technical documentation regarding the Software. Hemisphere reserves the right to reduce and limit access to such support at anytime.

---

*Continued on next page*

5. **BACKUPS AND RECOVERY.** Licensee shall back-up all data used, created or stored by the Software on a regular basis as necessary to enable proper recovery of the data and related systems and processes in the event of a malfunction in the Software or any loss or corruption of data caused by the Software. Licensee shall assume all risks of loss or damage for any failure to comply with the foregoing.
6. **OWNERSHIP.** Hemisphere and its suppliers own all rights, title and interest in and to the Software and related materials, including all intellectual property rights. The Software is licensed to Licensee, not sold.
7. **TRADEMARKS.** "Hemisphere GNSS", "Crescent", "Eclipse" and the associated logos are trademarks of Hemisphere. Other trademarks are the property of their respective owners. Licensee may not use any of these trademarks without the consent of their respective owners.
8. **LIMITED WARRANTY.** Hemisphere warrants solely to the Licensee, subject to the exclusions and procedures set forth herein below, that for a period of one (1) year from the original date of purchase of the Product in which it is embedded (the "Warranty Period"), the Software, under normal use and maintenance, will conform in all material respects to the documentation provided with the Software and any media will be free of defects in materials and workmanship. For any Update, Hemisphere warrants, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater, that the Update, under normal use and maintenance, will conform in all material respects to the documentation provided with the Update and any media will be free of defects in materials and workmanship. Notwithstanding the foregoing, Hemisphere does not warrant that the Software will meet Licensee's requirements or that its operation will be error free.
9. **WARRANTY EXCLUSIONS.** The warranty set forth in Section (8) will not apply to any deficiencies caused by (a) the Product not being used as described in the documentation supplied to Licensee, (b) the Software having been altered, modified or converted in any way by anyone other than Hemisphere approved by Hemisphere, (c) any malfunction of Licensee's equipment or other software, or (d) damage occurring in transit or due to any accident, abuse, misuse, improper installation, lightning (or other electrical discharge) or neglect other than that caused by Hemisphere. Hemisphere GNSS does not warrant or guarantee the precision or accuracy of positions obtained when using the Software (whether standalone or embedded in a Product). The Product and the Software is not intended and should not be used as the primary means of navigation or for use in safety of life applications. The potential positioning and navigation accuracy obtainable with the Software as stated in the Product or Software documentation serves to provide only an estimate of achievable accuracy based on specifications provided by the US Department of Defense for GPS positioning and DGPS service provider performance specifications, where applicable.
10. **WARRANTY DISCLAIMER.** EXCEPT AS EXPRESSLY SET OUT IN THIS AGREEMENT, HEMISPHERE MAKES NO REPRESENTATION, WARRANTY OR CONDITION OF ANY KIND TO LICENSEE, WHETHER VERBAL OR WRITTEN AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS OF ANY KIND INCLUDING FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, ACCURACY, RELIABILITY OR THAT THE USE OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE AND HEREBY DISCLAIMS ALL REPRESENTATIONS, WARRANTIES AND CONDITIONS ARISING AS A RESULT OF CUSTOM, USAGE OR TRADE AND THOSE ARISING UNDER STATUTE.



11. **LIMITS ON WARRANTY DISCLAIMER.** Some jurisdictions do not allow the exclusion of implied warranties or conditions, so some of the above exclusions may not apply to Licensee. In that case, any implied warranties or conditions which would then otherwise arise will be limited in duration to ninety (90) days from the date of the license of the Software or the purchase of the Product. The warranties given herein give Licensee specific legal rights and Licensee may have other rights which may vary from jurisdiction to jurisdiction.
12. **CHANGE TO WARRANTY.** No employee or agent of Hemisphere is authorized to change the warranty provided or the limitation or disclaimer of warranty provisions. All such changes will only be effective if pursuant to a separate agreement signed by senior officers of the respective parties.
13. **WARRANTY CLAIM.** In the event Licensee has a warranty claim Licensee must first check for and install all Updates that are made available. The warranty will not otherwise be honored. Proof of purchase may be required. Hemisphere does not honor claims asserted after the end of the Warranty Period.
14. **LICENSEE REMEDIES.** In all cases which involve a failure of the Software to conform in any material respect to the documentation during the Warranty Period or a breach of a warranty, Hemisphere's sole obligation and liability, and Licensee's sole and exclusive remedy, is for Hemisphere, at Hemisphere's option, to (a) repair the Software, (b) replace the Software with software conforming to the documentation, or (c) if Hemisphere is unable, on a reasonable commercial basis, to repair the Software or to replace the Software with conforming software within ninety (90) days, to terminate this Agreement and thereafter Licensee shall cease using the Software. Hemisphere will also issue a refund for the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
15. **LIMITATION OF LIABILITY.** IN NO EVENT WILL HEMISPHERE BE LIABLE TO LICENSEE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL OR INDIRECT DAMAGES INCLUDING ARISING IN RELATION TO ANY LOSS OF DATA, INCOME, REVENUE, GOODWILL OR ANTICIPATED SAVINGS EVEN IF HEMISPHERE HAS BEEN INFORMED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGE. FURTHER, IN NO EVENT WILL HEMISPHERE'S TOTAL CUMULATIVE LIABILITY HEREUNDER, FROM ALL CAUSES OF ACTION OF ANY KIND, EXCEED THE TOTAL AMOUNT PAID BY LICENSEE TO HEMISPHERE TO PURCHASE THE PRODUCT. THIS LIMITATION AND EXCLUSION APPLIES IRRESPECTIVE OF THE CAUSE OF ACTION, INCLUDING BUT NOT LIMITED TO BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, TORT, BREACH OF WARRANTY, MISREPRESENTATION OR ANY OTHER LEGAL THEORY AND WILL SURVIVE A FUNDAMENTAL BREACH.
16. **LIMITS ON LIMITATION OF LIABILITY.** Some jurisdictions do not allow for the limitation or exclusion of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to Licensee and Licensee may also have other legal rights which may vary from jurisdiction to jurisdiction.
17. **BASIS OF BARGAIN.** Licensee agrees and acknowledges that Hemisphere has set its prices and the parties have entered into this Agreement in reliance on the limited warranties, warranty disclaimers and limitations of liability set forth herein, that the same reflect an agreed-to allocation of risk between the parties (including the risk that a remedy may fail of its essential purpose and cause consequential loss), and that the same forms an essential basis of the bargain between the parties. Licensee agrees and acknowledges that Hemisphere would not have been able to sell the Product at the amount charged on an economic basis without such limitations.

18. **PROPRIETARY RIGHTS INDEMNITY.** Hemisphere shall indemnify, defend and hold harmless Licensee from and against any and all actions, claims, demands, proceedings, liabilities, direct damages, judgments, settlements, fines, penalties, costs and expenses, including royalties and attorneys' fees and related costs, in connection with or arising out of any actual infringement of any third party patent, copyright or other intellectual property right by the Software or by its use, in accordance with this Agreement and documentation, PROVIDED THAT: (a) Hemisphere has the right to assume full control over any action, claim, demand or proceeding, (b) Licensee shall promptly notify Hemisphere of any such action, claim, demand, or proceeding, and (c) Licensee shall give Hemisphere such reasonable assistance and tangible material as is reasonably available to Licensee for the defense of the action, claim, demand or proceeding. Licensee shall not settle or compromise any of same for which Hemisphere has agreed to assume responsibility without Hemisphere's prior written consent. Licensee may, at its sole cost and expense, retain separate counsel from the counsel utilized or retained by Hemisphere.
19. **INFRINGEMENT.** If use of the Software may be enjoined due to a claim of infringement by a third party then, at its sole discretion and expense, Hemisphere may do one of the following:
- a. negotiate a license or other agreement so that the Product is no longer subject to such a potential claim
  - b. modify the Product so that it becomes non-infringing, provided such modification can be accomplished without materially affecting the performance and functionality of the Product
  - c. replace the Software, or the Product, with non-infringing software, or product, of equal or better performance and quality
- if none of the foregoing can be done on a commercially reasonable basis, terminate this license and Licensee shall stop using the Product and Hemisphere shall refund the price paid by Licensee less an amount on account of amortization, calculated on a straight-line basis over a deemed useful life of three (3) years.
20. The foregoing sets out the entire liability of Hemisphere and the sole obligations of Hemisphere to Licensee in respect of any claim that the Software or its use infringes any third party rights.
21. **INDEMNIFICATION.** Except in relation to an infringement action, Licensee shall indemnify and hold Hemisphere harmless from any and all claims, damages, losses, liabilities, costs and expenses (including reasonable fees of lawyers and other professionals) arising out of or in connection with Licensee's use of the Product, whether direct or indirect, including without limiting the foregoing, loss of data, loss of profit or business interruption. **TERMINATION.** Licensee may terminate this Agreement at any time without cause. Hemisphere may terminate this Agreement on 30 days notice to Licensee if Licensee fails to materially comply with each provision of this Agreement unless such default is cured within the 30 days. Any such termination by a party shall be in addition to and without prejudice to such rights and remedies as may be available, including injunction and other equitable remedies. Upon receipt by Licensee of written notice of termination from Hemisphere or termination by Licensee, Licensee shall at the end of any notice period (a) cease using the Software; and (b) return to Hemisphere (or destroy and provide a certificate of a Senior Officer attesting to such destruction) the Software and all related material and any magnetic or optical media provided to Licensee. The provisions of Sections 6), 7), 8), 9), 10), 15), 21), 26) and 27) herein shall survive the expiration or termination of this Agreement for any reason.

22. **EXPORT RESTRICTIONS.** Licensee agrees that Licensee will comply with all export control legislation of Canada, the United States, Australia and any other applicable country's laws and regulations, whether under the Arms Export Control Act, the International Traffic in Arms Regulations, the Export Administration Regulations, the regulations of the United States Departments of Commerce, State, and Treasury, or otherwise as well as the export control legislation of all other countries.
23. **PRODUCT COMPONENTS.** The Product may contain third party components. Those third party components may be subject to additional terms and conditions. Licensee is required to agree to those terms and conditions in order to use the Product.
24. **FORCE MAJEURE EVENT.** Neither party will have the right to claim damages as a result of the other's inability to perform or any delay in performance due to unforeseeable circumstances beyond its reasonable control, such as labor disputes, strikes, lockouts, war, riot, insurrection, epidemic, Internet virus attack, Internet failure, supplier failure, act of God, or governmental action not the fault of the non-performing party.
25. **FORUM FOR DISPUTES.** The parties agree that the courts located in Calgary, Alberta, Canada and the courts of appeal there from will have exclusive jurisdiction to resolve any disputes between Licensee and Hemisphere concerning this Agreement or Licensee's use or inability to use the Software and the parties hereby irrevocably agree to attorn to the jurisdiction of those courts. Notwithstanding the foregoing, either party may apply to any court of competent jurisdiction for injunctive relief.
26. **APPLICABLE LAW.** This Agreement shall be governed by the laws of the Province of Alberta, Canada, exclusive of any of its choice of law and conflicts of law jurisprudence.
27. **CISG.** The United Nations Convention on Contracts for the International Sale of Goods will not apply to this Agreement or any transaction hereunder.

**GENERAL.** This is the entire agreement between Licensee and Hemisphere relating to the Product and Licensee's use of the same, and supersedes all prior, collateral or contemporaneous oral or written representations, warranties or agreements regarding the same. No amendment to or modification of this Agreement will be binding unless in writing and signed by duly authorized representatives of the parties. Any and all terms and conditions set out in any correspondence between the parties or set out in a purchase order which are different from or in addition to the terms and conditions set forth herein, shall have no application and no written notice of same shall be required. In the event that one or more of the provisions of this Agreement is found to be illegal or unenforceable, this Agreement shall not be rendered inoperative but the remaining provisions shall continue in full force and effect.

---

# Warranty Notice

---

**COVERED PRODUCTS:** This warranty covers all products manufactured by Hemisphere GNSS and purchased by the end purchaser (the "Products"), unless otherwise specifically and expressly agreed in writing by Hemisphere GNSS.

**LIMITED WARRANTY:** Hemisphere GNSS warrants solely to the end purchaser of the Products, subject to the exclusions and procedures set forth below, that the Products sold to such end purchaser and its internal components shall be free, under normal use and maintenance, from defects in materials, and workmanship and will substantially conform to Hemisphere GNSS's applicable specifications for the Product, for a period of 12 months from delivery of such Product to such end purchaser (the "Warranty Period"). Repairs and replacement components for the Products are warranted, subject to the exclusions and procedures set forth below, to be free, under normal use and maintenance, from defects in material and workmanship, and will substantially conform to Hemisphere GNSS's applicable specifications for the Product, for 90 days from performance or delivery, or for the balance of the original Warranty Period, whichever is greater.

**EXCLUSION OF ALL OTHER WARRANTIES.** The LIMITED WARRANTY shall apply only if the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Hemisphere GNSS relevant User's Manual and Specifications, AND the Product is not modified or misused. The Product is provided "AS IS" and the implied warranties of MERCHANTABILITY and FITNESS FOR A PARTICULAR PURPOSE and ALL OTHER WARRANTIES,

express, implied or arising by statute, by course of dealing or by trade usage, in connection with the design, sale, installation, service or use of any products or any component thereof, are EXCLUDED from this transaction and shall not apply to the Product. The LIMITED WARRANTY is IN LIEU OF any other warranty, express or implied, including but not limited to, any warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE, title, and non-infringement.

**LIMITATION OF REMEDIES.** The purchaser's EXCLUSIVE REMEDY against Hemisphere GNSS shall be, at Hemisphere GNSS's option, the repair or replacement of any defective Product or components thereof. The purchaser shall notify Hemisphere GNSS or a Hemisphere GNSS's approved service center immediately of any defect. Repairs shall be made through a Hemisphere GNSS approved service center only. Repair, modification or service of Hemisphere GNSS products by any party other than a Hemisphere GNSS approved service center shall render this warranty null and void. The remedy in this paragraph shall only be applied in the event that the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Hemisphere GNSS's relevant User's Manual and Specifications, AND the Product is not modified or misused. NO OTHER REMEDY (INCLUDING, BUT NOT LIMITED TO, SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR CONTINGENT DAMAGES FOR LOST PROFITS, LOST SALES, INJURY TO PERSON OR PROPERTY, OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL LOSS) SHALL BE AVAILABLE TO PURCHASER, even if Hemisphere GNSS has been advised of the possibility of such damages. Without limiting the foregoing, Hemisphere GNSS shall not be liable for any damages of any kind resulting from installation, use, quality, performance or accuracy of any Product.

---

*Continued on next page*

**HEMISPHERE IS NOT RESPONSIBLE FOR PURCHASER'S NEGLIGENCE OR UNAUTHORIZED USES OF THE PRODUCT.** IN NO EVENT SHALL Hemisphere GNSS BE IN ANY WAY RESPONSIBLE FOR ANY DAMAGES RESULTING FROM PURCHASER'S OWN NEGLIGENCE, OR FROM OPERATION OF THE PRODUCT IN ANY WAY OTHER THAN AS SPECIFIED IN Hemisphere GNSS's RELEVANT USER'S MANUAL AND SPECIFICATIONS. Hemisphere GNSS is NOT

RESPONSIBLE for defects or performance problems resulting from (1) misuse, abuse, improper installation, neglect of Product; (2) the utilization of the Product with hardware or software products, information, data, systems, interfaces or devices not made, supplied or specified by Hemisphere GNSS; (3) the operation of the Product under any specification other than, or in addition to, the specifications set forth in Hemisphere GNSS's relevant User's Manual and Specifications; (4) damage caused by accident or natural events, such as lightning (or other electrical discharge) or fresh/ salt water immersion of Product; (5) damage occurring in transit; (6) normal wear and tear; or (7) the operation or failure of operation of any satellite-based positioning system or differential correction service; or the availability or performance of any satellite-based positioning signal or differential correction signal.

**THE PURCHASER IS RESPONSIBLE FOR OPERATING THE VEHICLE SAFELY.** The purchaser is solely responsible for the safe operation of the vehicle used in connection with the Product, and for maintaining proper system control settings. UNSAFE DRIVING OR SYSTEM CONTROL SETTINGS CAN RESULT IN PROPERTY DAMAGE, INJURY, OR DEATH.

The purchaser is solely responsible for his/her safety and for the safety of others. The purchaser is solely responsible for maintaining control of the automated steering system at all times. THE PURCHASER IS SOLELY RESPONSIBLE FOR ENSURING THE PRODUCT IS PROPERLY AND CORRECTLY INSTALLED, CONFIGURED, INTERFACED, MAINTAINED, STORED, AND OPERATED IN ACCORDANCE WITH Hemisphere GNSS's RELEVANT USER'S MANUAL AND SPECIFICATIONS. Hemisphere GNSS does not warrant or guarantee the positioning and navigation precision or accuracy obtained when using Products. Products are not intended for primary navigation or for use in safety of life applications. The potential accuracy of Products as stated in Hemisphere GNSS literature and/or Product specifications serves to provide only an estimate of achievable accuracy based on performance specifications provided by the satellite service operator (i.e. US Department of Defense in the case of GPS and differential correction service provider. Hemisphere GNSS reserves the right to modify Products without any obligation to notify, supply or install any improvements or alterations to existing Products.

**GOVERNING LAW.** This agreement and any disputes relating to, concerning or based upon the Product shall be governed by and interpreted in accordance with the laws of the State of Arizona.

**OBTAINING WARRANTY SERVICE.** In order to obtain warranty service, the end purchaser must bring the Product to a Hemisphere GNSS approved service center along with the end purchaser's proof of purchase. Hemisphere GNSS does not warrant claims asserted after the end of the warranty period. For any questions regarding warranty service or to obtain information regarding the location of any of Hemisphere GNSS approved service center, contact Hemisphere GNSS at the following address:

### **Outback Guidance**

**A Division of Hemisphere GNSS**

**2207 Iowa Street**

**Hiawatha, KS 66434**

**Phone: (800) 247-3808**

**[www.outbackguidance.com](http://www.outbackguidance.com)**

---



2207 Iowa Street

Hiawatha, KS 66434

Phone: (800) 247-3808

[www.outbackguidance.com](http://www.outbackguidance.com)